

Electron tubes

Book T6

1986

Geiger-Müller tubes

Elcoma – Philips Electronic Components and Materials Division – embraces a world-wide group of companies operating under the following names:

Miniwatt Signetics

Mullard VALVO

PHILIPS

Elcoma offers you a technological partnership in developing your systems to the full. A partnership to which we can bring

- world-wide production and marketing
- know-how
- systems approach
- continuity
- broad product line
- fundamental research
- leading technologies
- applications support
- quality

GEIGER-MÜLLER TUBES

	page	
Selection guide	1	
General		
Cross-reference guide	6	
	8	
General information	9	
Device data		



DATA HANDBOOK SYSTEM

Our Data Handbook System comprises more than 60 books with specifications on electronic components, subassemblies and materials. It is made up of four series of handbooks:

ELECTRON TUBES

BLUE

SEMICONDUCTORS

RED

INTEGRATED CIRCUITS

PURPLE

COMPONENTS AND MATERIALS

GREEN

The contents of each series are listed on pages iv to viii.

The data handbooks contain all pertinent data available at the time of publication, and each is revised and reissued periodically.

When ratings or specifications differ from those published in the preceding edition they are indicated with arrows in the page margin. Where application information is given it is advisory and does not form part of the product specification.

Condensed data on the preferred products of Philips Electronic Components and Materials Division is given in our Preferred Type Range catalogue (issued annually).

Information on current Data Handbooks and on how to obtain a subscription for future issues is available from any of the Organizations listed on the back cover.

Product specialists are at your service and enquiries will be answered promptly.

ELECTRON TUBES (BLUE SERIES)

The blue series of data handbooks comprises:

T1	Tubes for r.f. heating
T2a	Transmitting tubes for communications, glass types
T2b	Transmitting tubes for communications, ceramic types
Т3	Klystrons
T4	Magnetrons for microwave heating
T5	Cathode-ray tubes Instrument tubes, monitor and display tubes, C.R. tubes for special applications
Т6	Geiger-Müller tubes
Т8	Colour display systems Colour TV picture tubes, colour data graphic display tube assemblies, deflection units
Т9	Photo and electron multipliers
T10	Plumbicon camera tubes and accessories
T11	Microwave semiconductors and components
T12	Vidicon and Newvicon camera tubes
T13	Image intensifiers and infrared detectors
T15	Dry reed switches
T16	Monochrome tubes and deflection units Black and white TV picture tubes, monochrome data graphic display tubes, deflection units

SEMICONDUCTORS (RED SERIES)

The red series of data handbooks comprises:

S1

Diodes

	Small-signal silicon diodes, voltage regulator diodes (< 1,5 W), voltage reference diodes, tuner diodes, rectifier diodes
S2a	Power diodes
S2b	Thyristors and triacs
S3	Small-signal transistors
S4a	Low-frequency power transistors and hybrid modules
S4b	High-voltage and switching power transistors
S5	Field-effect transistors
S6	R.F. power transistors and modules
S7	Surface mounted semiconductors
S8a	Light-emitting diodes
S8b	Devices for optoelectronics Optocouplers, photosensitive diodes and transistors, infrared light-emitting diodes and infrared sensitive devices, laser and fibre-optic components
S9	Power MOS transistors
S10	Wideband transistors and wideband hybrid IC modules
S11	Microwave transistors
S12	Surface acoustic wave devices
S13	Semiconductor sensors

INTEGRATED CIRCUITS (PURPLE SERIES)

The purple series of data handbooks comprises:

EXIST	ING SERIES	Superseded by:
IC1	Bipolar ICs for radio and audio equipment	IC01N
IC2	Bipolar ICs for video equipment	IC02Na and IC02Nb
IC3	ICs for digital systems in radio, audio and video equipment	IC01N, IC02Na and IC02Nb
IC4	Digital integrated circuits CMOS HE4000B family	
IC5	Digital integrated circuits – ECL ECL10 000 (GX family), ECL100 000 (HX family), dedicate	IC08N ted designs
IC6	Professional analogue integrated circuits	ICO3N and Supplement to IC11N
IC7	Signetics bipolar memories	
IC8	Signetics analogue circuits	IC11N
IC9	Signetics TTL logic	IC09N and IC15N
IC10	Signetics Integrated Fuse Logic (IFL)	IC13N
IC11	Microprocessors, microcomputers and peripheral circuitry	IC14N

NEW SERIES		
IC01N	Radio, audio and associated systems Bipolar, MOS	(published 1985)
IC02Na	Video and associated systems Bipolar, MOS Types MAB8031AH to TDA1524A	(published 1985)
IC02Nb	Video and associated systems Bipolar, MOS Types TDA2501 to TEA1002	(published 1985)
IC03N	Integrated circuits for telephony	(published 1985)
IC04N	HE4000B logic family CMOS	
IC05N	HE4000B logic family — incased ICs CMOS	(published 1984)
IC06N*	High-speed CMOS; PC74HC/HCT/HCU Logic family	(published 1986)
IC07N	$\label{eq:high-speed} \mbox{High-speed CMOS; PC54/74HC/HCT/HCU} - \mbox{uncased ICs} \\ \mbox{Logic family}$	
IC08N	ECL 10K and 100K logic families	(published 1984)
IC09N	TTL logic series	(published 1986)
IC10N	Memories MOS, TTL, ECL	
IC11N	Linear LSI	(published 1985)
Supplement to IC11N	Linear LSI	(published 1986)
IC12N	Semi-custom gate arrays & cell libraries ISL, ECL, CMOS	
IC13N	Semi-custom Integrated Fuse Logic	(published 1985)
IC14N	Microprocessors, microcontrollers & peripherals Bipolar, MOS	(published 1985)

Note

IC15N

Books available in the new series are shown with their date of publication.

FAST TTL logic series

(published 1984)

^{*} Supersedes the IC06N 1985 edition and the Supplement to IC06N issued Autumn 1985.

COMPONENTS AND MATERIALS (GREEN SERIES)

The green series of data handbooks comprises:

C1	Programmable controller modules PLC modules, PC20 modules
C2	Television tuners, coaxial aerial input assemblies, surface acoustic wave filters
C3	Loudspeakers
C4	Ferroxcube potcores, square cores and cross cores
C5	Ferroxcube for power, audio/video and accelerators
C6	Synchronous motors and gearboxes
C7	Variable capacitors

C/ Variable capacitors

C8 Variable mains transformers

C10 Connectors

C9

C11 Varistors, thermistors and sensors

Piezoelectric quartz devices

C12 Potentiometers, encoders and switches

C13 Fixed resistors

C14 Electrolytic and solid capacitors

C15 Ceramic capacitors

C16 Permanent magnet materials

C17 Stepping motors and associated electronics

C18 Direct current motors

C19 Piezoelectric ceramics

C20 Wire-wound components for TVs and monitors

C21* Assemblies for industrial use HNIL FZ/30 series, NORbits 60-, 61-, 90-series, input devices

C22 Film capacitors

^{*} To be issued shortly.

SELECTION GUIDE

SELECTION GUIDE

Cylindrical tubes

type number	sen: f	siti or β	ve γ	counting rate at 10 ⁻² mGy/h ¹ (¹³⁷ Cs) count/s	sensitive length mm	plateau threshold	max. plateau length V	max. plateau slope %/V	max. dead time μs	background shielded count/min	dose rate range mGy/h
ZP1200			•	28	40	400	200	0.04	90	10	$10^{-3} - 10^2$
ZP12013				20	40	400	200	0.04	110	10	$10^{-3} - 40$
ZP1210				110	140	400	100	0.15	200	70	$3 \times 10^{-4} - 10$
ZP1220				180	240	400	100	0.15	210	90	$2 \times 10^{-4} - 3$
ZP1250				10 ²	0.5	420	80	0.40	10	1	$1 - 3 \times 10^{5}$
ZP1300				300 ²	8	500	100	0.30	11	1	$10^{-1} - 2 \times 10^4$
ZP13013				350 ²	8	500	100	0.30	13	1	$10^{-1} - 2 \times 10^4$
ZP13023				350 ²	8	500	100	0.30	13	9	$10^{-1} - 2 \times 10^4$
ZP1310				1600 ²	16	500	150	0.15	15	2	$2 \times 10^{-2} - 4 \times 10^{3}$
ZP13133				1600 ²	16	500	150	0.15	15	2	$10^{-2} - 3 \times 10^{3}$
ZP1320		0		9	28	500	150	0.08	45	12	$3 \times 10^{-3} - 2 \times 10^{2}$
ZP13212		0		9	28	500	150	0.08	45	12	$3 \times 10^{-3} - 10^{2}$
ZP1330		0		65	75	450	350	0.02	70	30	$6 \times 10^{-4} - 10$

Window tubes

type number	nsiti for β	ve γ	counting rate at 10 ⁻² mGy/h (¹³⁷ Cs) ¹ count/s	window φ/type mm	plateau threshold V	max. plateau length V	max. plateau slope %/V	max. dead time µs	background shielded count/min	dose rate range mGy/h
701400	 • •	•	V (0)						10	10-3 - 10
ZP1400	•		25	9 c	400	200	0.04	90		$10^{-3} - 10$
ZP1401		0	25	9 a	400	200	0.04	90	10	
ZP1410		0	32	19.8 a	450	250	0.02	175	15	$10^{-3} - 10$
ZP1430	. 0	0	44	27.8 a	450	250	0.04	190	25	$6 \times 10^{-4} - 6$
ZP1431		0	44	27.8 c	450	250	0.04	190	25	$6 \times 10^{-4} - 6$
ZP1441		0	16	19.8 a	500	200	0.09	65	5	$3 \times 10^{-3} - 10^{2}$
ZP1442		0	16	19.8 c	500	200	0.09	65	8	$3 \times 10^{-3} - 10^{2}$
ZP1451		0	29	27.8 a	500	250	0.07	60	9	$10^{-3} - 20$
ZP1452		0	29	27.8 c	500	250	0.07	60	18	$10^{-3} - 20$
ZP1470			38	24.1 b	550	150	0.15	70	25	$10^{-3} - 20$
ZP1480		0	24	17 d	400	100	0.20	120	30	$10^{-3} - 20$
ZP1481		0	24	17 d	400	100	0.20	120	30	$10^{-3} - 20$
ZP1490			29	28 a	450	250	0.05	30	15	$10^{-3} - 20$

Notes

1. 1R = 8.69 mGy

2. Counting rate at 10 mGy

3. With compensating filter

Window thickness (mg/cm²)

a: 1.5 to 2.0 d: 2.5 to 3.0

b: 1.5 to 2.5 e: 2.5 to 3.5

c: 2.0 to 3.0

f: 3.5 to 4.0

X-ray sensitive tubes

type number	sensitive for $\alpha \beta \gamma$	counting rate at 10 ⁻² mGy/h ¹ (^{1 3 7} Cs) count/s	window φ/type mm	plateau threshold V	max. plateau length V	max. plateau slope %/V	max. dead time μs	background shielded count/min	dose rate range mGy/h
ZP1600	6.0 - 20*	660	19.8 e	1600	400	0.07	110	25	_
ZP1610	2.5 - 40*	-	7 x 18 f	_	oper	ating volt	age 155	0 V	_

*keV

Cosmic ray guard tube

						-			
ZP1700	•	_	-	800	400	0.03	1000	70	$3 \times 10^{-4} - 3 \times 10^{-1}$

High temperature tubes

type number	nsiti for β	ve γ	counting rate at 10 ⁻² mGy/h ¹ (¹³⁷ Cs) count/s	sensitive length mm	plateau threshold V	max. plateau length V	max. plateau slope %/V	max. dead time μ s	background shielded count/min	dose rate range mGy/h
ZP1800		•	190	419	700	150	0.08	75	28	2 × 10 ⁻⁴ - 4
ZP1810		•	13	51	650	250	0.08	75	25	$3 \times 10^{-3} - 40$
ZP1820		•	110	203	450	250	0.06	100	65	$3 \times 10^{-4} - 4$
ZP1830			170	313	450	250	0.06	100	100	$2 \times 10^{-4} - 2$
ZP1840		•	8	32	850	200	0.08	50	15	$4 \times 10^{-3} - 10^{2}$
ZP1850		•	36	89	875	200	0.10	100	50	$10^{-3} - 20$
ZP1860			80	22	875	200	0.10	100	75	$4 \times 10^{-4} - 4$

Notes

- 1. 1R = 8.69 mGy
- 2. Counting rate at 10 mGy
- 3. With compensating filter

Window thickness (mg/cm²)

a: 1.5 to 2.0 d: 2.5 to 3.0

b: 1.5 to 2.5 e: 2.5 to 3.5

c: 2.0 to 3.0 f: 3.5 to 4.0



GENERAL

GEIGER-MÜLLER TUBES CROSS REFERENCE GUIDE

ZP type no.	185 type no.	MX type no.	US type no
ZP1200	18503	MX146	_
ZP1210	18520	MX120/01	_
ZP1220	18545	MX145	_
ZP1230*†	_	MX180	_
ZP1240*†		MX119	
ZP1300	18529	MX163	
ZP1310	18509	MX151	-
ZP1311*††	_	MX189	-
ZP1311*††	-	ZP1100	-
ZP1320	18550	MX164	_
ZP1330	18555	MX177	_
ZP1400	18504	MX147	_
ZP1410	18505	MX148	_
ZP1430	18526	MX169	_
ZP1431	18506	MX149	
ZP1441	18515	MX152	-
ZP1451	18536	MX166	
ZP1460*†	18546/01	MX167/01	-
ZP1470	_	MX123	
ZP1480	_	MX168/02	_
ZP1481	_	MX168	_
ZP1500*†	_	ZP1083	_
ZP1501*†	-	ZP1080	_
ZP1520*†	18525	MX124/01	_
ZP1530*†	-	MX142	_
ZP1600	18507	MX159	_
ZP1610	18511	MX161	_
ZP1700	18518	MX155	_
ZP1800	-	_	171G
ZP1810		_	181G2
ZP1820	_	_	78L
ZP1830	_	_	79L
ZP1840		_	560N
ZP1850	_	_	90NB3
ZP1860	_	_	912NB3

^{*} data available on request

[†] obsolete

^{††} obsolescent

GEIGER-MÜLLER TUBES CROSS REFERENCE GUIDE

185 type no.	ZP type no.
18503	ZP1200
18504	ZP1400
18505	ZP1410
18506	ZP1431
18507	ZP1600
18509	ZP1310
18511	ZP1610
18515	ZP1441
18518	ZP1700
18520	ZP1210
18525	ZP1520*†
18526	ZP1430
18529	ZP1300
18536	ZP1451
18548	ZP1220
18546/01	ZP1460*†
18550	ZP1320
18555	ZP1330
1	

MX type no.	ZP type no.
MX119	ZP1240*†
MX120/01	ZP1210
MX123	ZP1470
MX124/01	ZP1520*†
MX142	ZP1530*†
MX145	ZP1220
MX146	ZP1200
MX147	ZP1400
MX148	ZP1410
MX149	ZP1431
MX151	ZP1320
MX152	ZP1441
MX155	ZP1700
MX159	ZP1600
MX161	ZP1610
MX163	ZP1300
MX164	ZP1320
MX166	ZP1451
MX167/01	ZP1460*†
MX168	ZP1481
MX168/02	ZP1480
MX169	ZP1430
MX177	ZP1330
MX180	ZP1230*†
MX189	ZP1311*††
ZP1080	ZP1501*†
ZP1083	ZP1500*†
ZP1100	ZP1311*†1

US type no.	ZP type no
171G	ZP1800
181G2	ZP1810
78L	ZP1820
79L	ZP1830
560N	ZP1840
90NB3	ZP1850
912NB3	ZP1860

^{*} data available on request

[†] obsolete

^{††} obsolescent

RADIATION QUANTITIES AND UNITS

In previous issues of this handbook, the (exposure) dose rate has been given as röntgen/hr (R/hr), but this unit is being phased out internationally.

Absorbed dose will be used in future, expressed in the new unit gray (Gy).

Absorbed dose is a measure of energy deposition in any medium by all types of ionizing radiation and

Since an exposure of 1 R results in an energy deposition of 869 x 10^{-5} J/kg in air it follows that 1 R is equivalent to 869 x 10^{-5} Gy or 8.69 mGy.

Consequently this handbook gives data for the counting rate as a function of the absorbed dose rate in air as:

count/s and mGy/h

quantity	old unit	new unit	relationship	
exposure dose	röntgen	no special unit	1 R = produces in a ions carrying a char of: 2.58 x 10 ⁻⁴ C/kg	
absorbed dose	rad	gray	1 rad = 10 ⁻² J/kg 1 Gy = 1 J/kg = 100 rad 1 mGy = 100 mrad	

GENERAL INFORMATION GEIGER-MÜLLER TUBES

Where appropriate, the terminology used conforms to the following publications:— IEC50-531, IEC100, IEC151-25.

1 GENERAL

- 1.1 Geiger-Müller radiation counter tubes (G.M. tubes) are intended to detect alpha particles, beta particles, gamma or X-radiation.
- 1.2 A G.M. tube is a gas-filled device which reacts to individual ionizing events, thus enabling them to be counted.
- 1.3 A G.M. tube consists basically of an electrode at a positive potential (anode) surrounded by a metal cylinder at a negative potential (cathode). The cathode forms part of the envelope or is enclosed in a glass envelope. Ionizing events are initiated by quanta or particles entering the tube either through the window or through the cathode and colliding with the gas molecules.
- 1.4 The gas filling consists of a mixture of one or more rare gases and a quenching agent.
- 1.5 Quenching is the termination of the ionization current pulse in a G.M. tube. Effective quenching in our tubes is determined by the combination of the quenching gas properties and the value of the anode resistor.
- The capacitance of a G.M. tube is that between anode and cathode, ignoring the capacitive
 effects of external connections.

3. OPERATING CHARACTERISTICS

3.1. Starting voltage

This is the lowest voltage applied to a G.M. tube at which pulses of 1 V amplitude appear across the anode resistor. See fig.1.

3.2 Plateau

This is the section of the counting rate versus voltage characteristic (with constant irradiation), over which the counting rate is substantially independent of the applied voltage. Unless otherwise stated, the plateau is measured at a counting rate of approximately 100 count/s.

3.3 Plateau threshold voltage

This is the lowest voltage applied which corresponds to the start of the plateau for the stated sensitivity of the measuring circuit. See fig.1.

3.4 Plateau length

This is the range of applied voltage over which the plateau extends. See fig.1.

3.5 Plateau slope

This is the change in counting rate over the plateau length, expressed in % per volt. See fig.1.

3.6 Recommended supply voltage

This is the supply voltage at which the G.M. tube should preferably be used. This voltage is normally chosen to be in the middle of the plateau. See fig.1.

OPERATING CHARACTERISTICS (continued)

3.7 Background

This is the counting rate in the absence of the radiation which the G.M. tube is intended to measure.

3.8 Dead time

This is the time interval, after the initiation of a discharge resulting in a normal pulse, during which the G.M. tube is insensitive to further ionizing events. See fig.4.




Fig.1

Plateau length:

$$V_{plateau} = V_{b2} - V_{b1}$$

V

Plateau slope (over the plateau length):

$$\frac{N_2 - N_1}{0.5 (N_1 + N_2)} \times \frac{1}{V_{plateau}} \times 100$$
 %/V

where N₁ is the counting rate at V_{b1} , and N₂ is the counting rate at V_{b2}

4. MEASURING CIRCUITS

4.1 The measuring equipment used to establish the G.M. tube data consists of the circuit given in the data, an emitter follower with a pulse shaper, a limiting amplifier and a scaler.

4.2 Measuring circuit A





Fig.2

Notes:

- The input resistance and capacitance of the measuring equipment are represented by R2 and C2 respectively.
- When applying a rectangular pulse at 1 with the tube inserted but short-circuited, C2 should be adjusted to give an undistorted pulse at 3. Under these conditions R1 x (C1 + stray capacitance) = R2 x C2.

4.3 Measuring circuit B



Tapping the load resistor at 5 in fig.3 reduces the influence of a capacitive load.

GENERAL G.M. TUBES

NOTES

5.1 Resolution (resolving) time (of a counting system or a counter).

This is the minimum time interval between two distinct ionizing events which enables both to be counted.

5.2 Recovery time


This is the minimum time interval between the initiation of a normal size pulse and the initiation of the next pulse of normal size. See fig.4.

5.3 Pulse amplitude

The pulse amplitude of a G.M. tube may be approximated by the equation:

$$P = b \times (V_{supply} - V_{starting})$$

where P = pulse amplitude



5.4 Anode resistor

Normally the tube should be operated with an anode resistor of the value indicated in the measuring circuit, or higher. Decreasing the value of the anode resistor not only decreases the dead time but also the plateau length. A decrease in resistance below the limiting value may affect tube life and lead to its early destruction.

The anode resistor should be connected direct to the anode connector of the tube to ensure that parasitic capacitances of leads will not excessively increase the capacitive load on the tube. An increase in capacitive load may increase the pulse amplitude, the pulse duration, the dead time and the plateau slope. In addition the plateau will be shortened appreciably. Shunt capacitances as high as 20 pF may **destroy** the tube, but lower values are also dangerous.

5.5 Maximum counting rate

The maximum counting rate is approximately $1/\tau$ (τ = dead time). For continuous stable operation it is recommended that the counting rate is adjusted to a value in the linear part of the counting rate/dose rate curve. In extreme cases the time constant RC (see fig.2) may exceed the dead time of the tube. If this is so, CI may be omitted, thus reducing the RC product. However, this could cause calibration problems in series equipment production if the stray capacitances in individual instruments show wide variations.

5.6 Tube sensitivity at extremely high dose rates.

At dose rates exceeding the recommended maximum, a G.M. tube will produce the maximum number of counting pulses per second, limited by its dead time and the circuit in which it is incorporated.

However, due to the characteristics of a specific circuit, the indicated counting rate may fall appreciably, even to zero.

If dose rates exceeding 10 times the recommended maximum for window tubes, or 100 times for cylinder tubes, are likely to be encountered, it is advisable to use a circuit that continuously indicates saturation.

5.7 Dead time losses

After every pulse, the tube is temporarily insensitive during a period known as the dead time (τ). Consequently, the pulses that occur during this period are not counted. At a counting rate of N count/s the tube will be dead during 100 \times N \times τ % of the time, so that approximately 100 \times N \times τ % of the counts will be lost.

If, in an experiment, the inaccuracy must be < 1%, N should be less than 1/100 τ count/s. Example: If τ = 20 μ s, an inaccuracy of 1% is reached at a counting rate of approximately 500 count/s.

5.8 Background

See definition under 3.7. The most important sources of background are:

- 1. Gamma radiation from the environment and from cosmic radiation.
- 2. Mesons from cosmic radiation.
- Beta particles from contamination and impurities of the materials from which the detector itself is made.
- Spontaneous discharge or pulses in the detector and the counting circuit that do not originate from radiation.

From published experimental data the gamma contribution accounts for approximately 70% of the background and a further 25% (approximately) is due to cosmic mesons. For the majority of G.M. tube applications, the background may be reduced to an acceptable level by shielding the tube with lead or steel. Thus most of the gamma contribution is eliminated. The values given in the data in count per minute are derived from averages over a longer duration.

5.9 Counting rate/dose rate curves

These are measured with the source perpendicular to the tube axis, at the recommended supply voltage. The curves shown are typical and are measured at room temperature. Deviation of approximately \pm 10% may occur.

5.10 Current/dose rate curves

These are measured with the source perpendicular to the tube axis. The curves shown are typical. Deviation of approximately \pm 20% may occur.

5.11 Dead time curves

These represent the dead time (see 3.8 and fig.4) as a function of the supply voltage, measured with pulsed X-radiation in the recommended circuit, unless otherwise stated. The curves shown are typical. The maximum value is stated under OPERATING CHARACTERISTICS. Note that a higher anode resistor results in a longer dead time.

GENERAL G.M. TUBES

NOTES (continued)

5.12 Energy response curves

These represent the energy sensitivity as a function of the radiation energy, measured in the recommended circuit and in the linear part of the counting rate/dose rate curve. The curves shown are typical.

5.13 Polar response curves

These represent the relative sensitivity as a function of the angle of irradiation (as defined in the drawing), measured in the recommended circuit. The curves shown are typical.

→ 5.14 Environmental

Tubes are submitted to shock and vibration tests. The values which are given for each tube are not limiting values.

→ 5.15 Temperature

The temperature range over which the tubes work satisfactorily is given for each type. When working at low temperatures it is recommended that the tube is operated in the first third of the plateau.

→ 5.16. Beta response.

This is measured using a point source $({}^9 \,{}^0\,{}^0\,{}^+\!{}^0\,{}^+\!{}^0)$ in direct contact with the tube and an extended source $({}^9 \,{}^0\,{}^+\!{}^0\,{}^+\!{}^+\!{}^0)$, area $({}^0 \,{}^0\,{}^+\!{}^0)$ at a distance of 1 cm from the tube. For the point source the response is expressed in counts per second per Becquerel (c/s/Bq). For the extended source the response is expressed in counts per second per Becquerel/cm² (c/s/Bq cm²). (One Becquerel is equivalent to one disintegration per second)

6. LIMITING VALUES

The limiting values of G.M. tubes are given in the Absolute Maximum Rating System in accordance with IEC Publication 134.

Absolute maximum ratings are limiting values of operating and environmental conditions, applicable to any electronic device of a specified type as defined by its published data, which should not be exceeded under the worst probable conditions.

These values are chosen by the device manufacturer to provide acceptable serviceability of the device. taking no responsibility for equipment variations, environmental variations and the effects of changes in operating conditions due to variations in the characteristics of the device under consideration and of all other electronic devices in the equipment.

The equipment manufacturer should design so that, initially and throughout life, no absolute maximum value for the intended service is exceeded with any device under the worst probable operating conditions with respect to supply voltage variation, equipment control adjustment load variation, signal variation, environmental conditions, and variations in characteristics of the device under consideration and of all other electronic devices in the equipment.

Note: When operated at a limiting value the tubes may not be expected to function in

Note: When operated at a limiting value the tubes may not be expected to function in accordance with the published operating characteristics. Under operating conditions where limiting values coincide or are combined with extreme counting rates, the tubes may not function in a typical way.

MOUNTING

G.M. tubes must not be clamped tightly in the vicinity of glass-metal seals. Great care must be taken in handling and fixing thin walled tubes. Mica windows are extremely fragile and must never be touched.

Low capacitance between anode and cathode is essential, i.e. the shortest possible connections between anode terminal and load resistor must be made.

Soldering to the anode pin or to the cathode wall may destroy the tube. Most types are provided with a cathode lead or strap. This lead should be used for connection to the cathode. Tubes with an anode pin are supplied with the appropriate connector (see fig.5). This must be used.




Fig.5

8. STORAGE AND HANDLING

The tube should not be stored at ambient temperatures outside the limits given under the heading LIMITING VALUES on the data sheets.

To prevent leakage between the anode and the cathode, the tube should be dry and clean. Condensation of water vapour may cause a short-circuit between anode and cathode.

9. OUTSIDE PRESSURE

In tubes provided with a mica window, the gas pressure outside the tube should neither be lower than 35 kPa (\approx 25 cm Hg) nor higher than the atmospheric pressure (unless otherwise stated) and changes in pressure should be gradual.

Care should be taken not to expose tubes with very thin envelopes to pressures substantially higher than atmospheric. Also it should be noted that tubes should not be subjected to substantial changes in air pressure.

10. ENERGY DEPENDENCE

The sensitivity of G.M. tubes to gamma radiation is influenced considerably by the energy of the radiation.

At energies above about 300 to 400 keV, the action of the tube is due to emission of electrons from the cathode and the higher the atomic number of the cathode material the greater will be the electron emission. Radiation with an energy of less than 300 to 400 keV is absorbed by the gas filling, the absorption increasing as the energy decreases. This gives rise to the characteristic peak in sensitivity which occurs at about 60 keV, below which the sensitivity decreases rapidly due to cut-off by the thickness or density of the cathode wall. By using an external filter a near linear sensitivity can be obtained.

11. LIFE

11.1 Storage life

If stored in a cool dry place, free from continuous or severe vibration, there is hardly any deterioration in the tube's characteristics. A storage life of years is not unusual.

Warning: generally, life end of a G.M. tube is indicated by an increasing slope and a shorter plateau. For older tubes, operation is recommended at the first third of the plateau.

11.2 Operational life

The operational life of a G.M. tube is expressed in counts (discharges). Theoretically the quenching gas, ionized during a discharge, should be re-combined between discharges. However, minute quantities will be chemically bound, no longer taking part in the quenching process. This will lead to a gradual reduction of the plateau length, and, for a given working voltage, to an increased counting rate. This will culminate in a continuous state of discharge of the tube, rendering it useless. Apart from the accumulated number of counts registered, the ambient temperature during operation is of prime importance to the life of the tube. At temperatures above 50 °C, changes in the

GENERAL G.M. TUBES

NOTES (continued)

gas mixture may occur, possibly reducing the total number of counts attainable. Short periods of operation (not exceeding 1 h) up to approximately 70 °C should not prove harmful, but life will progressively decrease with increasing temperature.

Thus, depending on application and circumstances, the quenching gas could be exhausted in as little as a few hours or theoretically last for many years.

For these reasons G.M. tubes cannot be guaranteed unconditionally for a specified period of time.


Exceeding the LIMITING VALUES Soldering to the tube body or pin Bending the anode pin Touching the mica window

may destroy the tube

12. MAXIMUM BETA ABSORPTION (percentages)

source	max. β energy	in mic	a window (mg/cm ²)	in meta	al envelope	(mg/cm ²)
	MeV	2	3	4	40	60	100
^{4 2} K	3.55	1	1	2	13	20	30
90Y+90Sr	2.27	1	3	3	23	32	48
3 2 P	1.71	3	4	5	33	44	63
8 9 Sr	1.46	3	4	5	40	51	70
^{2 4} Na	1.39	3	5	6	41	53	73
109Pd	1.00	4	6	8	54	68	85
3 6 CI	0.71	7	10	13	72	84	95
1 3 1	0.61	8	11	15	77	90	97
^{2 2} Na	0.54	8	13	17	81	92	98
⁴⁶ Sc	0.36	15	22	27	94	99	100
⁶⁰ Co	0.31	20	26	34	97	100	100
99Tc	0.29	21	30	37	99	100	100
4 5 Ca	0.25	24	33	42	100	100	100
^{3 5} S	0.17	36	49	59	100	100	100
1 4 C	0.16	39	51	62	100	100	100
³ H	0.02	100	100	100	100	100	100
Geiger⊣Mülle type numl		ZP1401 ZP1410 ZP1430 ZP1441 ZP1451	ZP1400 ZP1431 ZP1442 ZP1452 ZP1470 ZP1480	ZP1461	ZP1320 ZP1850 ZP1860	ZP1330	ZP1300 ZP1310

DEVICE DATA



GEIGER-MÜLLER TUBE

Halogen quenched γ radiation counter tube.

QUICK REFERENCE DATA


Dose rate range	10 ⁻³ to 10 ²	mGy/h	
	10 ⁻⁴ to 10	R/h	
Plateau threshold voltage	400	V	
Plateau length	200	V	
Recommended supply voltage	500	V	
Chrome-iron cathode	250	mg/cm ²	

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm

Fig.1



CATHODE			-
Thickness	250	mg/cm ²	
Sensitive length	40	mm	
Material	chrome-iron		
ENVIRONMENTAL (Manufacturer's test cond	ditions)		
Shock (half sine wave 3 ms duration) - peak ac	cceleration 392	m/s^2	
Vibration (50 Hz continues sine wave) - accele	eration 24.5	m/s^2	
FILLING	neon, argon, halogen		
CAPACITANCE			
Anode to cathode	1.1	pF	
TUBE WEIGHT	7	g	4

19

OPERATING CHARACTERISTICS (Ambient temperature ≈ 25 °C)

OF ETTATING OFFICE COMPONENTS	20 0/		
Measured in circuit of Fig.2			
Starting voltage	max.	325	V
Plateau threshold voltage	max.	400	V
Plateau length		200	V
Recommended supply voltage		500	V
Plateau slope	max.	0.04	%/V
Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended			
supply voltage	max.	10	count/mir
Dead time, at recommended supply voltage	max.	90	μs
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	4.7	Ω M
Anode voltage	max.	600	V
Ambient temperature			
continuous operating	max.	+70	oC
	min.	-40	oC
storage	max.	+75	oC

5 x 10¹⁰

count

LIFE EXPECTANCY Life expectancy at ≈ 25 °C MEASURING CIRCUIT

 $R_1 = 10 \text{ M}\Omega$ $R_2 = 220 \text{ k}\Omega$ $C_1 = 1 \text{ pF*}$







Fig.2

^{*}See General Information (paragraph 5.5)





Typical current as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage

GEIGER-MÜLLER TUBE

Halogen quenched γ radiation counter tube fitted in a filter. The energy response is flat to within +25 % over the range 50 keV to 1.25 MeV referred to $^{13.7}$ Cs (661 keV). The ZP1201 is an energy compensated version of the ZP1200.


QUICK REFERENCE DATA

Dose rate range	10 ⁻³ to 40	mGy/h
	10 ⁻⁴ to 5	R/h
Plateau threshold voltage	400	V
Plateau length	200	V
Recommended supply voltage	500	V
Chrome-iron cathode	250	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm



note: cathode strap should be connected to the tube as shown

CATHODE (ZP1200)

 Thickness
 250 mg/cm²

 Sensitive length
 40 mm

Material chrome-iron

ENVIRONMENTAL (Manufacturer's test conditions)

Shock (half sine wave 3 ms duration) — peak acceleration 392 m/s²

FILLING neon, argon, halogen

CAPACITANCE

Anode to cathode 1.2 pF

TUBE WEIGHT 38

OPERATING CHARACTERISTICS (Ambient temperature ≈ 25 °C)

Measured in	circuit	of	Fig.2
-------------	---------	----	-------

Measured in circuit of Fig.2			
Starting voltage	max.	325	V
Plateau threshold voltage	max.	400	V
Plateau length		200	V
Recommended supply voltage		500	V
Plateau slope	max.	0.04	%/V
Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended		10	count/min
supply voltage	max.	10	count/mm
Dead time, at recommended supply voltage	max.	110	μs
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	4.7	$M\Omega$
Anode voltage	max.	600	V
Ambient temperature continuous operating	max. min.	+70 -40	°C

+75

5 x 1010

max.

oc

count

LIFE EXPECTANCY

Life expectancy at \approx 25 $^{\rm o}{\rm C}$

MEASURING CIRCUIT

 $R_1 = 10 M\Omega$ $R_2 = 220 k\Omega$ $C_1 = 1 pF*$

storage







Fig.2

^{*}See General Information (paragraph 5.5)






Typical current as a function of dose rate (137Cs)



Typical energy response relative to 137Cs



Typical polar responses (normalised to 100% at 0°)



Halogen quenched γ radiation counter tube. Also available in low background version ZP1210/01.

QUICK REFERENCE DATA


Dose rate range	3 x 10 ⁻⁴ to 10	mGy/h
	4×10^{-5} to 1	R/h
Plateau threshold voltage	400	V
Plateau length	100	V
Recommended supply voltage	450	V
Chrome-iron cathode	525	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm

Fig.1



Tube must not be clamped within 30 mm of either end.

$C \Lambda$	ruc	IDE
CA	ITI	UE

Thickness	525	mg/cm ²
Sensitive length	140	mm
Material	chrome-iron	
ENVIRONMENTAL (Manufacturer's test conditions)		
Shock (half sine wave 3 ms duration) — peak acceleration	392	m/s^2
FILLING	neon, argon, halogen	
CAPACITANCE		
Anode to cathode	4.5	pF
TUBE WEIGHT	85	g

OPERATING CHARACTERISTICS (Ambient temperature ≈ 25 °C)

Measured in circuit of Fig.2			
Starting voltage	max.	350	V
Plateau threshold voltage	max.	400	V
Plateau length		100	V
Recommended supply voltage		450	V
Plateau slope	max.	0.15	%/V
Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended	max.	70	count/min.
supply voltage		1	- 1
Dead time, at recommended supply voltage	max.	200	μs
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	2.7	Ω M
Anode voltage	max.	500	V
Ambient temperature continuous operating	max. min.	+70 -40	°C
storage	max.	+75	oC
LIFE EXPECTANCY			
Life expectancy at \approx 25 °C	5	× 10 ¹⁰	count

Life expectancy at ≈ 25 °C **MEASURING CIRCUIT**







Fig.2




Typical counting rate as a function of dose rate ($^{1\,3\,7}$ Cs)



Typical current as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage



Typical energy response relative to ¹³⁷Cs

Halogen quenched γ radiation counter tube. Also available in low background version ZP1220/01.

QUICK REFERENCE DATA


Dose rate range	2 x 10 ⁻⁴ to 3	mGy/h	-
	2×10^{-5} to 3×10^{-1}	R/h	
Plateau threshold voltage	400	V	
Plateau length	100	V	
Recommended supply voltage	450	V	
Chrome-iron cathode	525	mg/cm ²	

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm





Tube must not be clamped within 30 mm of either end.

CAT	uc	IDE
CAI	LIC	DL

TUBE WEIGHT

Thickness	525	mg/cm ²
Sensitive length	240	mm
Material	chrome-iron	
ENVIRONMENTAL (Manufacturer's test conditions)		
Shock (half sine wave 3 ms duration) $-$ peak acceleration	392	m/s^2
FILLING	neon, argon, halogen	
CAPACITANCE		
Anode to cathode	10	pF

g

140

OPERATING CHARACTERISTICS (Ambient temperature \approx 25 $^{\rm O}$ C)

Measured in circuit of Fig.2			
Starting voltage	max.	350	V
Plateau threshold voltage	max.	400	V
Plateau length		100	V
Recommended supply voltage		450	V
Plateau slope	max.	0.15	%/V
Background (shielded with 50 mm Pb with an inner liner of 3 mm AI), at recommended		00	acust/min
supply voltage	max.	90	count/min.
Dead time, at recommended supply voltage	max.	210	μs
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	2.7	Ω M
Anode voltage	max.	500	V
Ambient temperature			2.5
continuous operating	max.	+70	oC OC
	min.	-40	oC
storage	max.	+75	oC
LIFE EXPECTANCY			

5 x 10¹⁰ Life expectancy at \approx 25 °C count

MEASURING CIRCUIT







Fig.2



Typical counting rate as a function of dose rate (137Cs)



Typical current as a function of dose rate (137Cs)



Typical energy response relative to 137Cs

Halogen quenched γ and high energy β (> 0.5 MeV) radiation counter tube.

QUICK REFERENCE DATA


Dose rate range	10^{-1} to 2×10^4	mGy/h
	10^{-2} to 2×10^{3}	R/h
Plateau threshold voltage	500	V
Plateau length	100	V
Recommended supply voltage	550	V
Chrome-iron cathode	80 to 100	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm

Fig.1



	D7070	5.A	
CATHODE			-
Thickness	80 to 100	mg/cm ²	
Sensitive length	7	mm	
Material	chrome-iron		
ENVIRONMENTAL (Manufacturer's test conditions)			
Shock (half sine wave 3 ms duration) — peak acceleration	392	m/s^2	
Vibration (50 Hz continuous sine wave) - acceleration	49	m/s^2	
FILLING	helium, neon, halogen		
CAPACITANCE			
Anode to cathode	0.7	pF	
TUBE WEIGHT	0.5	g	4-

OPERATING CHARACTERISTICS (Ambient temperature \approx 25 $^{\rm O}$ C)

Measured	in	circ	uit	of	Fig.2	
----------	----	------	-----	----	-------	--

Measured in circuit of Fig.2			
Starting voltage	max.	400	V
Plateau threshold voltage	max.	500	V
Plateau length		100	V
Recommended supply voltage		550	V
Plateau slope	max.	0.3	%/V
Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended			
supply voltage	max.	1	count/min
Dead time, at recommended supply voltage	max.	11	μs
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	2.2	Ω M

Anode resistor	min.	2.2	$M\Omega$
Anode voltage	max.	600	V
Ambient temperature continuous operating	max. min.	+70 -40	°C
storage	max.	+75	oC

5 x 10¹⁰ count

LIFE EXPECTANCY

— Life expectancy at ≈ 25 °C

MEASURING CIRCUIT

 $R_1 = 2.2 M\Omega$ $R_2 = 47 k\Omega$

 $C_1 = 1 pF*$







Fig.2

^{*}See General Information (paragraph 5.5)






Typical current as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage

ZP1300



Typical energy response relative to $^{1\,3\,7}\,\mathrm{Cs}$




Halogen quenched γ radiation counter tube fitted in a filter. The energy response is flat to within \pm 15% over the range 80 keV to 1.25 MeV referred to 137 Cs (661 keV). The ZP1301 is an energy compensated version of the ZP1300. Also available with long life artificial background as ZP1302.

QUICK REFERENCE DATA

Dose rate range	10^{-1} to 2 x 10^4	mGy/h
	10^{-2} to 2 x 10^{3}	R/h
Plateau threshold voltage	500	V
Plateau length	100	V
Recommended supply voltage	550	V
Chrome-iron cathode	80 to 100	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.



note: cathode strap should be connected to the tube as shown

CATHODE (ZP1300)

Thickness	80 to 100	mg/cm ²
Sensitive length	8	mm
Material	chrome iron	

ENVIRONMENTAL (Manufacturer's test conditions)

Shock (half sine wave 3 ms duration) - peak acceleration	392	m/s^2
--	-----	---------

511.1110	hallow were belease
FILLING	helium, neon, halogen

CAPACITANCE		
Anode to cathode	0.95	pF
TUBE WEIGHT	20	g

OPERATING CHARACTERISTICS (Ambient temperature ≈ 25 °C)

Measured in circuit of Fig.2

Starting voltage	max.	400	V
Plateau threshold voltage	max.	500	V
Plateau length		100	V
Recommended supply voltage		550	V
Plateau slope	max.	0.3	%/V
Background (shielded with 50 mm Pb with an inner liner of 3 mm AI) at 550 V	max.	1	count/min
Dead time at 550 V	max.	13	μs
LIMITING VALUES (Absolute max. rating system)			

2.2 Anode resistor min. $M\Omega$ Anode voltage 600 V max. oC +70 Ambient temperature max. continuous operating min. -40oC +75 oC storage max.

LIFE EXPECTANCY

► Life expectancy at ≈ 25 °C

5 x 10¹⁰ count

MEASURING CIRCUIT

 $R_1 = 2.2 M\Omega$ $R_2 = 47 k\Omega$

 $C_1 = 1 pF*$






Fig.2


^{*}See General Information (paragraph 5.5)




Typical counting rate as a function of dose rate (137Cs)



Typical current as a function of dose rate (137Cs)



Typical energy response relative to 137Cs



Typical polar responses (normalised to 100% at 0°)



Halogen quenched γ and high energy β (> 0.5 MeV) radiation counter tube

QUICK REFERENCE DATA


GOICK HEI EHENCE DATA		
Dose rate range	2×10^{-2} to 4×10^{3}	mGy/h
	2×10^{-3} to 5×10^{2}	R/h
Plateau threshold voltage	500	V
Plateau length	150	V
Recommended supply voltage	575	V
Chrome-iron cathode	80 to 100	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm

Fig.1



CATHODE

CATHODE			
Thickness	80 to 100	mg/cm ²	
Sensitive length	16	mm	
Material	chrome-iron		
ENVIRONMENTAL (Manufacturer's test conditions)			•
Shock (half sine wave 3 ms duration) — peak acceleration	392	m/s^2	
FILLING	helium, neon, halogen		
CAPACITANCE			
Anode to cathode	1.2	pF	
TUBE WEIGHT	0.7	g -	-

OPERATING CHARACTERISTICS (Ambient temperature \approx 25 $^{\rm o}$ C)

Measured	in	circu	iit	of	Fig.2
----------	----	-------	-----	----	-------

Starting voltage	max.	380	V
Plateau threshold voltage	max.	500	V
Plateau length		150	V
Recommended supply voltage		575	V
Plateau slope	max.	0.15	%/V
Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended			
supply voltage	max.	2	count/min
Dead time, at recommended supply voltage	max.	15	μs

LIMITING VALUES (Absolute max. rating system)

Anode resistor	min.	2.2	IVIZ
Anode voltage	max.	650	V
Ambient temperature			
continuous operating	max.	+70	oC

min. -40 °C storage max. +75 °C

LIFE EXPECTANCY

Life expectancy at ≈ 25 °C 5 x 10¹⁰ count

MEASURING CIRCUIT

 $R_1 = 2.2 \text{ M}\Omega$ $R_2 = 47 \text{ k}\Omega$ $C_1 = 1 \text{ pF*}$







Fig.2

^{*}See General Information (paragraph 5.5)






Typical current as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage



Typical energy response relative to $^{1\,3\,7}\,\mathrm{Cs}$



Halogen quenched γ radiation counter tube fitted in a filter. The energy response is flat to within $\pm 15\%$ over the range 50 keV to 1.25 MeV referred to $^{1.3.7}$ Cs (661 keV).

The ZP1313 is an energy compensated version of the ZP1310.

QUICK REFERENCE DATA


Dose rate range	10^{-2} to 3×10^{3}	mGy/h
	10^{-3} to 4×10^{2}	R/h
Plateau threshold voltage	500	V
Plateau length	150	V
Recommended supply voltage	575	V
Chrome-iron cathode	80 to 100	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm

Fig.1



note: cathode strap should be connected to the tube as shown

CATHODE (ZP1310)

Thickness	80 to 100	mg/cm ²
Sensitive length	16	mm
Material	chrome-iron	

ENVIRONMENTAL (Manufacturer's test conditions) Shock (half sine wave 3 ms duration) — peak acceleration

FILLING	helium, neon, halogen

CAPACITANCE

Anode to cathode	2.0	pF
TUDE WEIGHT	7.0	п

 m/s^2

392

OPERATING CHARACTERISTICS	(Ambient temperature ≈ 25 °C)
----------------------------------	-------------------------------

Measured in circuit of Fig.2				
Starting voltage		max.	380	V
Plateau threshold voltage		max.	500	V
Plateau length			150	V
Recommended supply voltage			575	V
Plateau slope		max.	0.15	%/V
Background shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended				
supply voltage	*	max.	2	count/min
Dead time, at recommended supply voltage		max.	15	μs
LIMITING VALUES (Absolute max, rating system)				
Anode resistor		min.	2.2	$M\Omega$
Anode voltage		max.	650	V
Ambient temperature				
continuous operating		max.	+70	oC
		min.	-40	oC
storage		max.	+75	oC

LIFE EXPECTANCY


Life expectancy at \approx 25 °C

MEASURING CIRCUIT

 $R_1 = 2.2 M\Omega$

 $R_2 = 47 k\Omega$


 $C_1 = 1 pF*$




 5×10^{10}

count


ZP1313




Typical counting rate as a function of dose rate (137Cs)




Typical current as a function of dose rate (137Cs)




Typical dead time as a function of supply voltage



Typical energy response (side response) relative to 137Cs



Typical polar responses (normalised to 100% at 0°)



Typical polar responses (normalised to 100% at 0°)

Halogen quenched γ and β (> 0.25 MeV) radiation counter tube.

QUICK REFERENCE DATA


Dose rate range	3×10^{-3} to 2×10^{2}	mGy/h
	4×10^{-4} to 20	R/h
Plateau threshold voltage	500	V
Plateau length	150	V
Recommended supply voltage	575	V
Chrome-iron cathode	32 to 40	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm

Fig.1



CATHODE

Inickness	32 to 40	mg/cm ²	
Sensitive length	28	mm	
Material	chrome-iron		
ENVIRONMENTAL (Manufacturer's test conditions)			
Shock (half sine wave 3 ms duration) $-$ peak accelerate	tion 392	m/s^2	
FILLING	neon, argon, halogen		
CAPACITANCE			
Anode to cathode	1.1	pF	
TUBE WEIGHT	1.0	g	

Measured in circuit of Fig.2

modulation in on out of Figure			
Starting voltage	max.	380	V
Plateau threshold voltage	max.	500	V
Plateau length		150	V
Recommended supply voltage		575	V
Plateau slope	max.	0.08	%/V
Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended supply voltage	max.	12	count/min
	max.	45	
Dead time, at recommended supply voltage	IIIdX.	45	μs
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	2.2	$M\Omega$
Anode voltage	max.	650	V
Ambient temperature			
continuous operating	max.	+70	°C
	min.	-40	oC
storage	max.	+75	oC
LIFE EXPECTANCY			
Life expectancy at \approx 25 °C	5 2	× 10 ¹⁰	count

MEASURING CIRCUIT

 $R_1 = 4.7 M\Omega$

 $R_2 = 100 \text{ k}\Omega$

 $C_1 = 1 pF^*$







Fig.2

^{*}See General Information (paragraph 5.5)






Typical current as a function of dose rate ($^{1\,3\,7}$ Cs)



Typical dead time as a function of supply voltage



Typical energy response relative to 137Cs



DEVELOPMENT DATA

This data sheet contains advance information and specifications are subject to change without notice.


GEIGER-MÜLLER TUBE


Halogen quenched γ radiation counter tube fitted in a filter. The energy response is flat to within +20 % over the range 40 keV to 1.25 MeV referred to ¹³⁷ Cs (661 keV). The ZP1321 is an energy -20 compensated version of the ZP1320.

QUICK REFERENCE DATA

GOICK HET ENENCE DATA			
Dose rate range	3×10^{-3} to 10^{2}	mGy/h	
	4×10^{-4} to 10	R/h	
Plateau threshold voltage	500	V	
Plateau length	150	V	
Recommended supply voltage	575	V	
Chrome-iron cathode	32 to 40	mg/cm ²	

This data must be read in conjunction with General Information Geiger-Müller tubes.







M2236

CATHODE (ZP1320)

Thickness	32 to 40 mg/		
Sensitive length	27 mm		
Material	chrome-iron		

ENVIRONMENTAL (Manufacturer's test conditions)

Shock (half sine wave 3 ms duration) — peak a	5000-7000-700-700-700-700-700-700-700-70	m/s²
FILLING	neon, argon, halogen	

CAPACITANCE

Anode to cathode	1.3	pF
TUBE WEIGHT	23	g

Measured in circuit of Fig.2

Starting voltage

max. Plateau threshold voltage max.

500 150 Plateau length

Recommended supply voltage 575 0.08 %/V Plateau slope max.

Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended

15 count/min supply voltage max. Dead time, at recommended supply voltage max. 55 μs

380

LIMITING VALUES (Absolute max. rating system)

2.2 $M\Omega$ Anode resistor min. Anode voltage 650 max.

OC +70 continuous operating max. min. -40 oC OC +75 storage max.

LIFE EXPECTANCY

Ambient temperature

5 x 1010 Life expectancy at ≈ 25 °C count

MEASURING CIRCUIT

 $R_1 = 4.7 M\Omega$

 $R_2 = 100 \text{ k}\Omega$

 $C_1 = 1 pF*$






Fig.2


^{*}See General Information (paragraph 5.5)




Typical counting rate as a function of dose rate (137Cs)




Typical current as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage



Typical energy response relative to $^{1\,3\,7}\,\mathrm{Cs}$



Typical polar responses (normalised to 100% at 0°)

Halogen quenched γ and β (> 0.3 MeV) radiation counter tube for use in damp and/or saline atmosphere.

QUICK REFERENCE DATA


Dose rate range	 6 x 10 ⁻⁴ to 10 7 x 10 ⁻⁵ to 1	mGy/h R/h
Plateau threshold voltage	450	V
Plateau length	350	V
Recommended supply voltage	625	V
Chrome-iron cathode	40 to 60	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm





The cathode is covered with a corrosion resistant coating.

CATHODE

Construction cylindrical wall with strengthening ribs 40 to 60 mg/cm² Thickness between strengthening ribs 75 Sensitive length mm Material chrome-iron **ENVIRONMENTAL** (Manufacturer's test conditions)

Shock (half sine wave 3 ms duration) - peak acceleration 392 m/s^2

CAPACITANCE

FILLING

Anode to cathode 4.0 pF **TUBE WEIGHT** 9.0

neon, argon, halogen

	Measured	in	circuit	of	Fig.2
--	----------	----	---------	----	-------

Starting voltage	

Plateau threshold voltage

Plateau length

Recommended supply voltage

Plateau slope

Background (shielded with 50 mm Pb with an inner liner of 3 mm AI), at recommended

supply voltage

Dead time, at recommended supply voltage

LIMITING VALUES (Absolute max. rating system)
Anode resistor

Anode voltage
Ambient temperature

continuous operating

storage

Life expectancy at ≈ 25 °C

LIFE EXPECTANCY

→ BETA RESPONSE

Point source (90 Sr/90 Y) between ribs:

Extended source $(90 \,\mathrm{Sr}/90 \,\mathrm{Y})$ in direct contact:

→ MEASURING CIRCUITS

 $R = 2.2 M\Omega$





Fig.2 Manufacturer's measuring circuit



400

450

350

625 0.02

30

70

2.2

800

+70

-40

+75

0.24

2.1

5 x 1010

V

%/V

MS

 $M\Omega$

oC

OC

00

count

c/s/Bq

c/s/Bq cm⁻²

count/min

max.

max.

max.

max.

max.

min.


max.

max.


min.

max.


Fig.3 For optimum performance at very high dose rates this circuit may be used




Typical counting rate as a function of dose rate (137Cs)




Typical current as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage



Typical energy response relative to 137Cs



End window halogen quenched β and γ radiation counter tube.


QUICK REFERENCE DATA


GOIOR HEI ENERGE DATA		
Dose rate range	10 ⁻³ to 10 ²	mGy/h
	10 ⁻⁴ to 10	R/h
Plateau threshold voltage	400	V
Plateau length	200	V
Recommended supply voltage	500	V
Chrome-iron cathode	250	mg/cm ²
Mica window (9 mm diameter)	2.0 to 3.0	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm





WINDOW

Thickness	2.0 to 3.0	mg/cm ²
Useful diameter	9	mm
Material	mica	

CATHODE

Thickness	250	mg/cm ²
Sensitive length	39	mm
	1	

Material chrome-iron

ENVIRONMENTAL

Shock (half sine wave 3 ms duration) - peak acceleration	392	m/s^2
Vibration (50 Hz continuous sine wave) - acceleration	24.5	m/s^2

FILLING neon, argon, halogen

CAPACITANCE

Anode to cathode	1.1	pF
TUBE WEIGHT	7.0	g

Measured in circuit of Fig.2

Starting voltage	max.	325	V
Plateau threshold voltage	max.	400	V
Plateau length		200	V
Recommended supply voltage		500	V
Plateau slope	max.	0.04	%/V

Background (shielded with 50 mm Pb with

an inner liner of 3 mm Al), at recommended max. supply voltage Dead time, at recommended supply voltage max.

LIMITING VALUES (Absolute max. rating system).				
Anode resistor	min.	4.7	$M\Omega$	
Anode voltage	max.	600	V	
Ambient temperature continuous operating	max.	+70	°C	

count/min.

μs

c/s/Bq

c/s/Bq cm⁻²

10

90

-40oC min. +75 oC storage max.

LIFE EXPECTANCY

5 × 10¹⁰ Life expectancy at ≈ 25 °C count

▶ BETA RESPONSE

Point source (90 Sr/90 Y)	0.25
Extended source (90 Sr/90 Y)	0.42

MEASURING CIRCUIT

 $R_1 = 10 M\Omega$ $R_2 = 220 \text{ k}\Omega$

 $C_1 = 1 pF*$







Fig.2

^{*}See General Information (paragraph 5.5)





Typical current as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage

Dimensions in mm

GEIGER-MÜLLER TUBE

End window halogen quenched α , β and γ radiation counter tube.


QUICK REFERENCE DATA

Dose rate range	10 ⁻³ to 10 ²	mGy/h
	10 ⁻⁴ to 10	R/h
Plateau threshold voltage	400	V
Plateau length	200	V
Recommended supply voltage	500	V
Chrome-iron cathode	250	mg/cm ²
Mica window (9 mm diameter)	1.5 to 2.0	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Fig.1



	W	IN	DO	W
--	---	----	----	---

Thickness	1.5 to 2.0	mg/cm ²
Useful diameter	9	mm
Material	mica	

CATHODE

Thickness	250	mg/cm ²
Sensitive length	39	mm
Material	chrome-iron	

Material chrome-iron

ENVIRONMENTAL

Shock (half sine wave 3 ms duration) - peak acceleration	392	m/s^2
Vibration (50 Hz continuous sine wave) - acceleration	24.5	m/s^2

FILLING

CAPACITANCE		
Anode to cathode	1.1	pF

TUBE WEIGHT	7.0	g
TODE WEIGHT		•

neon, argon, halogen

Measured in circuit of Fig.2			
Starting voltage	max.	325	V
Plateau threshold voltage	max.	400	V
Plateau length		200	V
Recommended supply voltage		500	V
Plateau slope	max.	0.04	%/V
Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended			
supply voltage	max.	10	count/min
Dead time, at recommended supply voltage	max.	90	μs
LIMITING VALUES (Absolute max. rating system).			
Anode resistor	min.	4.7	Ω M
Anode voltage	max.	600	V
Ambient temperature			
continuous operating	max.	+70	oC
	min.	-40	oC
storage	max.	+75	oC


LIFE EXPECTANCY

Life expectancy at \approx 25 °C

MEASURING CIRCUIT

 $R_1 = 10 M\Omega$ $R_2 = 220 k\Omega$

 $C_1 = 1 pF^*$





5 x 10¹⁰

count


Fig.2

^{*}See General Information (paragraph 5.5)





Typical current as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage


End window halogen quenched α , β and γ radiation counter tube.

OLUM	DEFE	DENIOE	DATA
UUILK	nere	RENCE	DAIA

TUBE WEIGHT

Dose rate range	10 ⁻³ to 10	mGy/h
	10 ⁻⁴ to 1	R/h
Plateau threshold voltage	450	V
Plateau length	250	V
Recommended supply voltage	575	V
Chrome-iron cathode	910	mg/cm ²
Mica window (19.8 mm diameter)	1.5 to 2.0	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.



34

Measured in circuit of Fig.2			
Starting voltage	max.	350	V
Plateau threshold voltage	max.	450	V
Plateau length		250	V
Recommended supply voltage		575	V
Plateau slope	max.	0.02	%/V
Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended		45	. /- :-
supply voltage	max.	15	count/min.
Dead time, at recommended supply voltage	max.	175	μs
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	2.2	$M\Omega$
Anode voltage	max.	700	V
Ambient temperature			
continuous operating	max.	+70	oC
	min.	-40	oC
storage	max.	+75	oC
LIFE EXPECTANCY			
Life expectancy at \approx 25 $^{\rm o}{\rm C}$	5	5×10^{10}	count

→ MEASURING CIRCUITS

 $R = 10 M\Omega$




Fig.2 Manufacturer's measuring circuit






Fig.3 For optimum performance at very high dose rates this circuit may be used



Typical counting rate as a function of dose rate (137Cs)



End window halogen quenched α , β and γ radiation counter tube.


QUICK REFERENCE DATA

GOIOR HEI EHENOL DATA		
Dose rate range	6 x 10 ⁻⁴ to 6	mGy/h
	7×10^{-5} to 7×10^{-1}	R/h
Plateau threshold voltage	450	V
Plateau length	250	V
Recommended supply voltage	575	V
Chrome-iron cathode	980	mg/cm ²
Mica window (27.8 mm diameter)	1.5 to 2.0	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm



WINDOW

FILLING

Thickness	1.5 to 2.0	mg/cm ²
Useful diameter	27.8	mm
Material	mica	
CATHODE		
Thickness	980	mg/cm ²
Sensitive length	37	mm
Material	chrome-iron	

ENVIRONMENTAL (Manufacturer's test conditions) Shock (half sine wave 3 ms duration) - peak acceleration

TILLING	ricon, argon, narogen	
CAPACITANCE		
Anode to cathode	3.5	pF

TUBE WEIGHT 51 g

 m/s^2

392

neon argon halogen

Measured	in	circuit	of	Fig.2

Starting voltage	
Plateau threshold voltage	
Plateau length	

Recommended supply voltage

Plateau slope

Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended supply voltage

LIMITING VALUES (Absolute max. rating system)

Anode resistor Anode voltage Ambient temperature continuous operating

storage

LIFE EXPECTANCY

Life expectancy at ≈ 25 °C MEASURING CIRCUIT

 $R_1 = 10 M\Omega$

 $R_2 = 220 k\Omega$

 $C_1 = 1 pF*$

575 0.04 %/V max. 25 count/min max. 230 -- Dead time, at recommended supply voltage max. μs min. 4.7 $M\Omega$ 700 max. oC max.. +70 -40 oC min. OC +75 max. 5 × 10¹⁰ count

375

450

250

V

max.

max.






Fig.2

^{*}See General Information (paragraph 5.5)



Typical counting rate as a function of dose rate (137Cs)




Typical dead time as a function of supply voltage

End window halogen quenched β and γ radiation counter tube.

QUICK REFERENCE DATA

Dose rate range	6 x 10 ⁻⁴ to 6	mGy/h
	7×10^{-5} to 7×10^{-1}	R/h
Plateau threshold voltage	450	V
Plateau length	250	V
Recommended supply voltage	575	V
Chrome-iron cathode	980	mg/cm ²
Mica window (27.8 mm diameter)	2.0 to 3.0	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.



	11 D7660a (7275127)		
WINDOW			
Thickness	2.0 to 3.0	mg/cm ²	
Useful diameter	27.8	mm	
Material	mica		
CATHODE			
Thickness	980	mg/cm ²	
Sensitive length	37	mm	
Material	chrome-iron		
ENVIRONMENTAL (Manufacturer's test conditions) Shock (half sine wave 3 ms duration) - peak acceleration	392	m/s²	4
FILLING	neon, argon, halogen		
CAPACITANCE			
Anode to cathode	3.5	pF	
TUBE WEIGHT	51	g	-

Measured in circuit of Fig.2			
Starting voltage	max.	375	V
Plateau threshold voltage	max.	450	V
Plateau length		250	V
Recommended supply voltage		575	V
Plateau slope	max.	0.04	%/V
Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended supply voltage	max.	25	count/min
Dead time, at recommended supply voltage	max.	190	μs
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	4.7	Ω M
Anode voltage	max.	700	V
Ambient temperature			

oC

oC

oc

count

c/s/Bq

c/s/Bq cm⁻²

+70

-40

+75

0.32

2.05

5 X 10¹⁰

max.

min.

max.

LIFE EXPECTANCY

Life expectancy at \approx 25 °C

continuous operating

BETA RESPONSE

storage

Point source (90 Sr/90 Y)

Extended source (90Sr/90Y)

MEASURING CIRCUIT

 $R_1 = 10 M\Omega$

 $R_2 = 220 \text{ k}\Omega$

 $C_1 = 1 pF *$






Fig.2

^{*}See General Information (paragraph 5.5)



Typical counting rate as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage


End window halogen quenched α , β and γ radiation counter tube for measurement of low levels of radiation in combination with a guard counter tube, e.g. ZP1700.

QUICK REFERENCE DATA

TUBE WEIGHT

Dose rate range	3×10^{-3} to 10^{2}	mGy/h
	3×10^{-4} to 10	R/h
Plateau threshold voltage	500	V
Plateau length	200	V
Recommended supply voltage	600	V
Chrome-iron cathode	910	mg/cm ²
Mica window (19.8 mm diameter)	1.5 to 2.0	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.



g

14

OPERATING CHARACTERISTICS (Ambient temperature ≈ 25 °C)

Measured	in circuit of Fig.2
Starting v	oltage

Starting voltage max. 350 V
Plateau threshold voltage max. 500 V

Plateau length 200 V
Recommended supply voltage 600 V

Plateau slope max. 0.09 %/V

Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended supply voltage max.

Background in anti-coincidence circuit
with guard counter tube ZP1700 (shielded)
with 100 mm Fe and 30 mm Pb), at

recommended supply voltage, Fe outside max. 1.2 count/min Dead time, at recommended supply voltage max. 65 μ s

5

count/min

LIMITING VALUES (Absolute max. rating system)

Anode resistor min. 2.2 M Ω Anode voltage max. 700 V

 Ambient temperature continuous operating
 max. +70 °C min. -40 °C

 storage
 max. +75 °C

LIFE EXPECTANCY

Life expectancy at ≈ 25 °C 5 x 10¹⁰ count

MEASURING CIRCUIT

 $R_1 = 4.7 M\Omega$ $R_2 = 100 k\Omega$

 $C_1 = 1 pF*$






Fig.2

^{*}See General Information (paragraph 5.5)



Typical counting rate as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage

End window halogen guenched β and γ radiation counter tube.

QUICK REFERENCE DATA

 3×10^{-3} to 10^{2} Dose rate range mGy/h 3 x 10⁻⁴ to 10 R/h Plateau threshold voltage 500 Plateau length 200 Recommended supply voltage 600

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Mica window (19.8 mm diameter)

Chrome-iron cathode


Dimensions in mm

mq/cm²

mq/cm²

910

2.0 to 3.0



WINDOW

2.0 to 3.0 mg/cm² Thickness Useful diameter 19.8 mm mica Material

CATHODE

Thickness 910 ma/cm² Sensitive length 12 mm Material chrome-iron

ENVIRONMENTAL (Manufacturer's test conditions) Shock (half sine wave 3 ms duration) - peak acceleration

neon, argon, halogen

FILLING

CAPACITANCE

1.0 pF Anode to cathode **TUBE WEIGHT** 14 g

June 1986

 m/s^2

OPERATING CHARACTERISTICS (Ambient temperature ≈ 25 °C)

350

500

200

600

0.09

8

65

2.2

700

+70

-40

+75

0.41

5 X 1010

max.

max.

max.

max.

max.

min.

max.

max.

min.

max.

V

V

μs

 $M\Omega$

OC

OC

OC

count

c/s/Ba 1.13 c/s/Bq cm-2

%/V

count/min

Measured in circuit of Fig.2

Starting voltage

Plateau threshold voltage

Plateau length

Recommended supply voltage

Plateau slope Background (shielded with 50 mm Pb with

an inner liner of 3 mm Al), at recommended

supply voltage Dead time, at recommended supply voltage

LIMITING VALUES (Absolute max. rating system)

Anode resistor

Anode voltage Ambient temperature continuous operating

storage

LIFE EXPECTANCY Life expectancy at ≈ 25 °C


→ BETA RESPONSE

Point source (90 Sr/90 Y) Extended source (90 Sr/90 Y)

MEASURING CIRCUIT


 $R_1 = 4.7 M\Omega$ $R_2 = 100 \text{ k}\Omega$

 $C_1 = 1 pF *$




*See General Information (paragraph 5.5)

106 June 1986



Typical counting rate as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage

End window halogen quenched α , β and γ radiation counter tube for measurement of low levels of radiation in combination with a guard counter tube, e.g. ZP1700.


QUICK REFERENCE DATA


Dose rate range	10 ⁻³ to 20	mGy/h
	10 ⁻⁴ to 2	R/h
Plateau threshold voltage	500	V
Plateau length	250	V
Recommended supply voltage	625	V
Chrome-iron cathode	980	mg/cm ²
Mica window (27.8 mm diameter)	1.5 to 2.0	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm





neon, argon, halogen

WINDOW

Thickness Useful diameter

Material

CATHODE

Thickness Sensitive length

Material

ENVIRONMENTAL (Manufacturer's test conditions)

Shock (half sine wave 3 ms duration) - peak acceleration

CAPACITANCE

FILLING

Anode to cathode

TUBE WEIGHT

980 mg/cm² 16 mm

chrome-iron

mica

 m/s^2 392

1.4 pF 22 g

August 1985


_			-	
	OPERATING CHARACTERISTICS (Ambient temperature ≈ 25 °C)		1)	
	Measured in circuit of Fig.2			
	Starting voltage	max.	375	V
	Plateau threshold voltage	max.	500	V
	Plateau length		250	V
	Recommended supply voltage		625	V
	Plateau slope	max.	0.07	%/V
	Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended supply voltage	max.	9	count/min
	Background in anti-coincidence circuit with guard counter tube ZP1700 (shielded) with 100 mm Fe and 30 mm Pb), at recommended supply voltage, Fe outside	max.	2	count/min
	Dead time, at recommended supply voltage	max.	60	μs
	LIMITING VALUES (Absolute max. rating system)			
	Anode resistor	min.	4.7	Ω M
	Anode voltage	max.	750	V
	Ambient temperature			
	continuous operating	max.	+70	°C
		min.	-40	°C
	storage	max.	+75	oC
	LIFE EXPECTANCY			

MEASURING CIRCUIT

Life expectancy at ≈ 25 °C

 $R_1 = 10 M\Omega$ $R_2 = 220 k\Omega$

 $C_1 = 1 pF^*$




5 x 10¹⁰


count

Fig.2

^{*}See General Information (paragraph 5.5)



Typical counting rate as a function of dose rate ($^{1\,3\,7}\,\text{Cs})$



Typical dead time as a function of supply voltage

End window halogen quenched β and γ radiation counter tube.

QUICK REFERENCE DATA

Dose rate range	10 ⁻³ to 20	mGy/h
	10 ⁻⁴ to 2	R/h
Plateau threshold voltage	500	V
Plateau length	250	V
Recommended supply voltage	625	V
Chrome-iron cathode	980	mg/cm ²
Mica window (27.8 mm diameter)	2.0 to 3.0	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA Dimensions in mm Fig.1 35 13 max 2.5 x 0.13 Cathode-strap 30.9 32 34 33 29.9 max 10 Anode-clip max Anode D8714 17.5 min 12 max WINDOW 34 max 2.0 to 3.0 mg/cm² Thickness Useful diameter 27.8 mm Material mica CATHODE mg/cm² Thickness 980 16 Sensitive length mm chrome-iron Material **ENVIRONMENTAL** (Manufacturer's test conditions) Shock (half sine wave 3 ms duration) - peak acceleration 392 m/s^2 FILLING neon, argon, halogen CAPACITANCE 1.4 pF Anode to cathode 22 **TUBE WEIGHT** g

OPERATING CHARACTERISTICS (Ambient temperature ≈ 25 °C)

Measured in circuit of Fig.2

Starting voltage

max.

375

500 V

250 V

625 V

0.07

18

60 MS

750

+70 oC

5 × 1010

0.38

2.27

-40 °C

+75 °C

4.7 MΩ

V

count

c/s/Bq

c/s/Bq cm⁻²

%/V

count/min

max.

max.

max.

min.

max.

max.

min.

max.

max.

Plateau threshold voltage

Plateau length

Recommended supply voltage

Plateau slope Background (shielded with 50 mm Pb with

an inner liner of 3 mm Al), at recommended

supply voltage

Dead time, at recommended supply voltage

LIMITING VALUES (Absolute max. rating system)

Anode resistor

Anode voltage

Ambient temperature

continuous operating

storage LIFE EXPECTANCY

Life expectancy at ≈ 25 °C **► IBETA RESPONSE**

Point source (90 Sr/90 Y) Extended source (90 Sr/90 Y)

MEASURING CIRCUIT $R_1 = 10 M\Omega$

 $R_2 = 220 k\Omega$

 $C_1 = 1 pF*$






Fig.2

^{*}See General Information (paragraph 5.5)



Typical counting rate as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage

End window halogen quenched β and γ radiation counter tube.

QUICK REFERENCE DATA


Dose rate range	10^{-3} to 2×10	mGy/h
	10 ⁻⁴ to 2	R/h
Threshold voltage	550	V
Plateau length	150	V
Recommended supply voltage	600	V
Chrome-iron cathode	690	mg/cm ²
Mica window thickness (24.1 mm diameter)	1.5 to 2.5	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm





WINDOW

Thickness	1.5 to 2.5	mg/cm ²
Effective diameter	24.1	mm
Material	mica	

CATHODE

Thickness	690	mg/cm ²
Sensitive length	26	mm
Material	chrome-iron	

ENVIRONMENTAL (Manufacturer's test conditions)		
Shock (half sine wave 3 ms duration) - peak acceleration	392	m/s^2

FILLING

neon, argon, halogen

CAPACITANCE 5.0 pF Anode to cathode TUBE WEIGHT 63 g OPERATING CHARACTERISTICS (Ambient temperature ≈ 25 °C) Measured in circuit of Fig.2 Starting voltage max. 500 Threshold voltage max. 550 150 Plateau length min. 625 Recommended supply voltage (mid-plateau) 0.15 %/V Plateau slope max. Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended 25 count/min supply voltage max. 70 Dead time, at recommended supply voltage max. μs LIMITING VALUES (Absolute max. rating system) Anode resistor min. 2.7 Ω M 700 Anode voltage max. oC +70 Ambient temperature max. OC -40 min. continuous operating +75 OC storage max. LIFE EXPECTANCY 5 x 1010 Life expectancy at ≈ 25 °C count **→** BETA RESPONSE Point source (90 Sr/90 Y) 0.35 c/s/Bq Extended source (90Sr/90Y) 2.44 c/s/Bq cm⁻² MEASURING CIRCUITS




Fig.2 Manufactuer's measuring circuit







Fig.3 For optimum performance at very high dose rates this circuit may be used



Typical current as a function of dose rate (137Cs)



Typical current as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage

End window halogen quenched β and γ radiation counter tubes.

QUICK REFERENCE DATA

Dose rate range	10^{-3} to 2 x 10	mGy/h
	10 ⁻⁴ to 2	R/h
Plateau threshold voltage	400	V
Plateau length	100	V
Recommended supply voltage	450	V
Chrome-iron cathode	2000	mg/cm ²
Mica window (17 mm diameter)	2.5 to 3.0	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA Dimensions in mm Fig.1 ZP1480 70max 65max anode ϕ 23.9 φ24 23.1 P.V.C. sheath over this length cathode 10 leads-nickel ϕ 0.3 M1009 80max ZP1481 76 74 29.5 27.5 10.5 anode φ 23.9 φ 27 23.1 26 P.V.C. sheath over this length cathode B2A base except M1010 for omission of groove

The ZP1481 may be used with socket type number MX199/SOCKET

ZP1480 ZP1481

	WINDOW			
	Thickness	2.5	5 to 3.0	mg/cm ²
	Useful diameter		17	mm
	Material		mica	
	CATHODE		2000	, ,
	Thickness		2000	mg/cm ²
	Sensitive length		. 38	mm
	Material	chro	me-iron	
-	ENVIRONMENTAL (Manufacturer's test conditions)			
	Shock (half sine wave 3 ms duration) — peak acceleration		392	m/s^2
	FILLING	neon, argon,	halogen	
	CAPACITANCE			
	Anode to cathode		3.5	pF
_	TUBE WEIGHT	ZP1480:	74	g
	TODE WEIGHT	ZP1481:	76	g
	OPERATING CHARACTERISTICS (Ambient temperature ≈ 25 °C	(C)		
	Measured in circuit of Fig.2			
	Starting voltage	max.	350	V
	Plateau threshold voltage	max.	400	V
	Plateau length		100	V
	Recommended supply voltage		450	V
	Plateau slope	max.	0.2	%/V
	Background (shielded with 50 mm Pb with			
	an inner liner of 3 mm Al), at recommended			
	supply voltage	max.	30	count/min
	Dead time, at recommended supply voltage	max.	120	μs
	LIMITING VALUES (Absolute max. rating system)			
	Anode resistor	min.	2.7	$M\Omega$
	Anode voltage	max.	500	V
	Ambient temperature			
	continuous operating	max.	+70	oC C
		min.	-40	°C
	storage	max.	+75	oC
	LIFE EXPECTANCY			
	Life expectancy at \approx 25 °C	5	x 10 ¹⁰	count

MEASURING CIRCUIT







Fig.2



Typical counting rate as a function of dose rate (137Cs)





DEVELOPMENT SAMPLE DATA

This information is derived from development samples made available for evaluation. It does not necessarily imply that the device will go into regular production.

GEIGER-MÜLLER TUBE

End window halogen quenched α , β and γ radiation counter tube for measurement of low levels of radiation.

QUICK REFERENCE GUIDE


		A CONTRACTOR OF THE PARTY OF TH
	10 ⁻³ to 20 10 ⁻⁴ to 2	mGy/h R/h
	450	V
	250	V
	575	V
max.	15	count/min.
	900	mg/cm ²
	1.5 to 2.0	mg/cm ²
	max.	10 ⁻⁴ to 2 450 250 575 max. 15 900


This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm

Fig. 1





WINDOW

 Thickness
 1.5 to 2.0
 mg/cm²

 Useful diameter
 28
 mm

 Material
 mica

 CATHODE
 8
 mm

Material chrome-iron

FILLING neon, argon, halogen

TUBE WEIGHT 20 g

OPERATING CHARACTERISTICS (Ambient temperature \approx 25 °C)

					F. 0
Measured	In	CITCL	JIT	OT	Fig.2

Weasured in circuit of Fig.2			
Starting voltage	max.	370	V
Plateau threshold voltage	max.	450	V
Plateau length		250	V
Recommended supply voltage		575	V
Plateau slope	max.	0.06	%/V
Background (shielded with 50 mm Pb with an inner liner of 3 mm Al)	max.	15	count/min
Dead time, at recommended supply voltage	max.	55	μs
LIMITING VALUES (Absulute max. rating system)			
Anode resistor	min.	4.7	$M\Omega$
Anode voltage	max.	700	V
Ambient temperature continuous operating	max. min.	+70 -40	oC oC

LIFE EXPECTANCY

Life expectancy at ≈ 25 °C

MEASURING CIRCUIT

 $R_1 = 4.7 \text{ M}\Omega$ $R_2 = 220 \text{ k}\Omega$

storage

 $C_1 = 1 pF*$




Fig.2

Graphs will be published in due course

oC

count

+75

5 × 10¹⁰


max.

^{*}See General Information (paragraph 5.5)

End window halogen quenched X-ray counter tube.

QUICK REFERENCE DATA

Energy range	6.0 to 20	keV
Wavelength range	0.06 to 0.2	nm
Plateau threshold voltage	1600	V
Plateau length	400	V
Recommended supply voltage	1800	V
Chrome-iron cathode	910	mg/cm ²
Mica window (19.8 mm diameter)	2.5 to 3.5	mg/cm ²



OPERATING CHARACTERISTICS (Ambient temperature \approx 25 $^{\rm O}$ C)

Measured in circuit of Fig.2

-			
Starting voltage	max.	1450	V
Plateau threshold voltage	max.	1600	V
Plateau length		400	V
Recommended supply voltage		1800	V
Plateau slope	max.	0.07	%/V
Background (shielded with 50 mm Pb with an inner liner of 3 mm Al), at recommended	may	25	count/min
supply voltage	max.	25	count/IIIII
Dead time, at recommended supply voltage	max.	110	μs
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	4.7	Ω M
Anode voltage	max.	2000	V
Ambient temperature			
continuous operating	max.	+70	oC
	min.	0	oC
storage	max.	+75	oC

1010

count

Life expectancy at ≈ 25 °C MEASURING CIRCUIT

LIFE EXPECTANCY

 $R = 4.7 M\Omega$






Fig.2



Typical dead time as a function of supply voltage



Side window organically quenched X-ray counter tube.

QUICK REFERENCE DATA


_		
Energy range	2.5 to 40	keV
Wavelength range	0.03 to 0.5	nm
Operating voltage range	1500 to 1800	V
Chrome-iron cathode		
Mica window (7 x 18 mm)	2.0 to 2.5	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm





CATHODE

Sensitive length	67	mm
Material	chrome-iron	

ENVIRONMENTAL (Manufacturer's test conditions) Shock (half sine wave 3 ms duration) - peak acceleration

FILLING	xenon and organic v	apour		
Gas pressure		40	kPa	

CAPACITANCE

TUBE WEIGHT

Anode to cathode	2.0	pF

g

 m/s^2

392

89

OPERATING CHARACTERISTICS (Ambient temperature \approx 25 $^{\rm o}$ C)


Measured in circuit of Fig.2			
Recommended supply voltage (note 1)		1550	V
Geiger threshold voltage	min.	1900	V
Operating voltage for pulse amplitude where $V_p \approx 1 \text{ mV}$ (note 2)	1460 to	1540	V
Operating voltage for pulse amplitude where $V_p \approx 10$ mV (note 2)	1690 to	1770	V
Energy resolution (notes 2 and 3) see page 3	max.	22	%
LIMITING VALUES (Absolute max. rating system)			
Anode voltage	max.	1850	V
Ambient temperature continuous operating	max. min.	+50 -20	°C

MEASURING CIRCUIT

 $R_1 = 2.2 k\Omega$

storage

 $R_2 = 100 \text{ k}\Omega$



oC


+50

max.


Fig.2

NOTES

- 1. For maximum tube life, the supply voltage should be kept as low as possible.
- 2. For Mn Kα radiation (5.9 keV)
- 3. $P = average pulse height, \Delta P = width of pulse height at half maximum value.$



Typical energy resolution curve




Halogen quenched cosmic ray guard counter tube for low background measurements in combination with radiation counter tube ZP1441 or ZP1451 in an anti-coincidence circuit.

QUICK REFERENCE DATA

Dose rate range	3×10^{-4} to 3×10^{-1} 4×10^{-5} to 3×10^{-2}	mGy/h R/h
Plateau threshold voltage	800	V
Plateau length	400	V
Recommended supply voltage	1000	V
Chrome-iron cathode	760	mg/cm ²

This data must be read in conjunction with General Information Geiger-Müller tubes.



CATHODE AND ANODE

TUBE WEIGHT

Thickness	760	mg/cm ²	
Material	chrome-iron		
ENVIRONMENTAL (Manufacturer's test conditions)			4-
Shock (half sine wave 3 ms duration) — peak acceleration	392	m/s ²	
FILLING	neon, argon, halogen		
CAPACITANCE			
Anode to cathode	8.0	pF	

June 1986

g

186

OPERATING CHARACTERISTICS (Ambient temperature ≈ 25 °C)

Measured in circuit of Fig.2

Starting voltage	max.	650	V	
Plateau threshold voltage	max.	800	V	
Plateau length		400	V	
Recommended supply voltage		1000	V	

Plateau slope Background (shielded with 100 mm Fe with

an inner liner of 30 mm Pb), at recommended supply voltage, Fe outside Dead time, at recommended supply voltage

LIMITING VALUES (Absolute max. rating system) Anode resistor

V Anode voltage max. 1200 Ambient temperature OC +70 continuous operating max. oC min. -40OC

LIFE EXPECTANCY

storage

Life expectancy at ≈ 25 °C


5 x 1010 count


MEASURING CIRCUITS

For use as a quard counter tube in an anti-coincidence in combination with ZP1441 or ZP1451, see Fig.3.

$$R = 10 M\Omega$$

$$R_1 = R_2 = 10 M\Omega$$





0.03

70

10

+75

1000

max.

max.

max.

min.

max.


%/V

μs


MΩ

count/min

Fig.3



Typical counting rate as a function of dose rate



Halogen quenched γ radiation counter tube for use at temperatures up to 200 °C. The temperature response is flat to within 8% over the range -40 °C to +200 °C.

QUICK REFERENCE DATA


Dose rate range	2×10^{-4} to 4	mGy/h
	2×10^{-5} to 5×10^{-1}	R/h
Plateau threshold voltage	700	V
Plateau length	150	V
Recommended supply voltage	775	V
Chrome-iron cathode, platinum plated		

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm (and inches)

Fig.1



tube must not be clamped within 80mm of either end M2693

CATHODE

Thickness	0.5	mm
Sensitive length	419 16.5	mm inches
Material	chrome iron, platinum plated	
FILLING	neon, argon, halogen	
CAPACITANCE		
Anode to cathode	11	pF
TUBE WEIGHT	57	g

OPERATING CHARACTERISTICS (Ambient temperature ≈ 25 °C)


Measured in circuit of Fig.2			
Starting voltage	max.	630	V
Plateau threshold voltage	max.	700	V
Plateau length		150	V
Recommended supply voltage		775	V
Plateau slope	max.	0.08	%/V
Background (shielded with 50 mm Pb with an inner liner of 6 mm Al), at recommended			
supply voltage	max.	25	count/min
Dead time, at recommended supply voltage	max.	75	μs
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	0	Ω M
A node voltage	max	850	V

Anode resistor	min.	0	$M\Omega$
Anode voltage	max.	850	V
Ambient temperature continuous operating	max. min.	+200 -40	°C
storage	max.	+150	oC

LIFE EXPECTANCY


Life expectancy at \approx 25 °C

MEASURING CIRCUIT




10¹⁰ count


Fig.2




Typical counting rate as a function of dose rate (137Cs)



Typical current as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage



Typical energy response relative to 137Cs

Halogen quenched γ radiation counter tube for use at temperatures up to 200 °C. The temperature response is flat to within 8% over the range -40 °C to +200 °C.

QUICK REFERENCE DATA


GOICK HEI ENENCE DATA		
Dose rate range	3 x 10 ⁻³ to 40 3 x 10 ⁻⁴ to 5	mGy/h R/h
Plateau threshold voltage	650	V
Plateau length	250	V
Recommended supply voltage	775	V
Chrome-iron cathode		

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm (and inches)

Fig.1



tube must not be clamped within 20mm of either end

CATHODE

0.5	mm
51	mm
2	inches
chrome iron, platinum plated	
neon, argon, halogen	
	51 2 chrome iron, platinum plated

CAPACITANCE

Anode to cathode	3	pF
TUBE WEIGHT	10	q

OPERATING CHARACTERISTICS (Ambient temperature	≈ 25 °C)		
Measured in circuit of Fig.2			
Starting voltage	max.	630	V
Plateau threshold voltage	max.	650	V
Plateau length		250	V
Recommended supply voltage		775	V
Plateau slope	max.	0.08	%/V
Background (shielded with 50 mm Pb with an inner liner of 6 mm Al), at recommended supply voltage	max.	25	count/min
Dead time, at recommended supply voltage	max.	75	μs
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min,	0	$M\Omega$
Anode voltage	max.	900	V
Ambient temperature			
continuous operating	max.	+200	oC
	min.	-40	oC
storage	max.	+150	oC
LIFE EXPECTANCY			
Life expectancy at \approx 25 $^{\rm o}{\rm C}$		1010	count







Fig.2




Typical counting rate as a function of dose rate (137Cs)




Typical current as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage



Typical energy response relative to $^{1\,3\,7}\,\mathrm{Cs}$



Halogen quenched γ radiation counter tube for use at temperatures up to 100 °C. The temperature response is flat to within 10% over the range -40 °C to +100 °C.

QUICK REFERENCE DATA


Dose rate range	3 x 10 ⁻⁴ to 4	mGy/h
•	3×10^{-5} to 4×10^{-1}	R/h
Plateau threshold voltage	450	V
Plateau length	250	V
Recommended supply voltage	575	V
Chrome-iron cathode		

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm (and inches)

Fig.1



tube must not be clamped within 60mm of either end

M2690

CATHODE

Thickness	0.25	mm
Sensitive length	203	mm
	8	inches
Material	chrome iron	
FILLING	neon, argon, halogen	

CAPACITANCE

Anode to cathode	6	pF
TUBE WEIGHT	34	a

OPERATING CHARACTERISTICS (Ambient temperature ≈ 25 °C)

Measured	in	circuit	of	Fig.2	
----------	----	---------	----	-------	--

Starting voltage	max.	400	V
Plateau threshold voltage	max.	450	V
Plateau length		250	V

Recommended supply voltage 575 V Plateau slope 0.06 max. %/V

65

100

10

1010

count/min

μs

 $M\Omega$

count

max.

max.

min.

Background (shielded with 50 mm Pb with an inner liner of 6 mm Al), at recommended

supply voltage Dead time, at recommended supply voltage

LIMITING VALUES (Absolute max. rating system)

Anode resistor

Anode voltage V max. 700 Ambient temperature continuous operating oC +100 max. oc

-40 min. storage +75 OC max.

LIFE EXPECTANCY

Life expectancy at ≈ 25 °C







Fig.2



Typical counting rate as a function of dose rate (137Cs)



Typical current as a function of dose rate (137Cs)



Typical energy response relative to 137Cs

Halogen quenched γ radiation counter tube for use at temperatures up to 100 °C. The temperature response is flat to within 10% over the range -40 °C to +100 °C.

QUICK REFERENCE DATA


Dose rate range	2×10^{-4} to 2 2×10^{-5} to 2×10^{-1}	mGy/h R/h
Plateau threshold voltage	450	V
Plateau length	250	V
Recommended supply voltage	575	V
Chrome-iron cathode		

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm (and inches)

Fig.1



tube must not be clamped within 75 mm of either end

M2691

CATHODE

Thickness	0.25	mm
Sensitive length	313	mm
	12.3	inches
Material	chrome iron	

FILLING neon, argon, halogen

CAPACITANCE

Anode to cathode 8 pF

TUBE WEIGHT 45 g

OPERATING CHARACTERISTICS (Ambient temperate	$are \approx 25$ °C)		
Measured in circuit of Fig.2			
Starting voltage	max.	400	V
Plateau threshold voltage	max.	450	V
Plateau length		250	V
Recommended supply voltage		575	V
Plateau slope	max.	0.06	%/V
Background (shielded with 50 mm Pb with an inner liner of 6 mm Al), at recommended			
supply voltage	max.	100	count/min
Dead time, at recommended supply voltage	max.	100	μς
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	10	Ω M
Anode voltage	max.	700	V
Ambient temperature			
continuous operating	max.	+100	oC
	min.	-40	oC
storage	max.	+75	oC
LIFE EXPECTANCY			
Life expectancy at \approx 25 °C		1010	count







Fig.2



Typical counting rate as a function of dose rate (137Cs)



Typical current as a function of dose rate ($^{1\,3\,7}\,\mathrm{Cs}$)



Typical energy response relative to 137Cs

Halogen quenched γ radiation counter tube for use at temperatures up to 175 °C. The temperature response is flat to within 5% over the range -20 °C to +175 °C.

QUICK REFERENCE DATA


Dose rate range	4×10^{-3} to 10^{2} 5 x 10^{-4} to 10	mGy/h R/h
Plateau threshold voltage	850	V
Plateau length	200	V
Recommended supply voltage	950	V
Chrome-iron cathode, platinum plated		

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm (and inches)

Fig.1



tube must not be clamped within 15mm of either end

M2692

CATHODE

0,1111022		
Thickness	1.2	mm
Sensitive length	32	mm
	1.25	inches
Material	chrome iron, platinum plated	
FILLING	neon, argon, halogen	

CAPACITANCE

Anode to cathode TUBE WEIGHT	2.5	pF
TUBE WEIGHT	14	g

June 1986

OPERATING CHARACTERISTICS (Ambient temperatur	re ≈ 25 °C)		
Measured in circuit of Fig.2			
Starting voltage	max.	825	V
Plateau threshold voltage	max.	850	V
Plateau length		200	V
Recommended supply voltage		950	V
Plateau slope	max.	0.08	%/V
Background (shielded with 50 mm Pb with an inner liner of 6 mm Al), at recommended supply voltage	max.	15	count/min
Dead time, at recommended supply voltage	max.	50	μς
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	1	$M\Omega$
Anode voltage	max.	1050	V
Ambient temperature continuous operating	max. min.	+175 -40	oC oC
storage	max.	+125	оС
LIFE EXPECTANCY			
Life expectancy at \approx 25 o C		1010	count







Fig.2




Typical counting rate as a function of dose rate (137Cs)



Typical current as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage



Typical energy response relative to $^{1\,3\,7}\,\mathrm{Cs}$



Halogen quenched β and γ radiation counter tube for use at temperatures up to 75 °C. The temperature response is flat to within 7% over the range -35 °C to +75 °C.

QUICK REFERENCE DATA


Dose rate range	10 ⁻³ to 20 10 ⁻⁴ to 2	mGy/h R/h
Plateau threshold voltage	875	V
Plateau length	200	V
Recommended supply voltage	975	V
Chrome-iron cathode		

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm (and inches)

Fig.1



tube must not be clamped within 30mm of either end

CATHODE

Inickness	30 - 40	mg/cm ²
Sensitive length	89	mm
	3.5	inches
Manager	The Barrier Control of the Control o	

Material chrome iron

FILLING neon, argon, halogen

CAPACITANCE Anode to cathode

pF **TUBE WEIGHT** 15 g

4

OPERATING CHARACTERISTICS (Ambient temperatu	$re \approx 25$ °C)		
Measured in circuit of Fig.2			
Starting voltage	max.	825	V
Plateau threshold voltage	max.	875	V
Plateau length		200	V
Recommended supply voltage		975	V
Plateau slope	max.	0.1	%/V
Background (shielded with 50 mm Pb with an inner liner of 6 mm Al), at recommended			
supply voltage	max.	50	count/min
Dead time, at recommended supply voltage	max.	100	μs
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	0	Ω M
Anode voltage	max.	1075	V
Ambient temperature			
continuous operating	max.	+75	oC
	min.	-35	oC
storage	max.	+75	oC
LIFE EXPECTANCY			
Life expectancy at ≈ 25 °C		1010	count







Fig.2




Typical counting rate as a function of dose rate (137Cs)




Typical current as a function of dose rate (137Cs)



Typical dead time as a function of supply voltage



Typical energy response relative to 137Cs



Halogen quenched β and γ radiation counter tube for use at temperatures up to 75 °C. The temperature response is flat to within 7% over the range -35 °C to +75 °C.

QUICK REFERENCE DATA


Dose rate range	4×10^{-4} to 4	mGy/h
	5×10^{-5} to 4×10^{-1}	R/h
Plateau threshold voltage	875	V
Plateau length	200	V
Recommended supply voltage	975	V
Chrome-iron cathode		

This data must be read in conjunction with General Information Geiger-Müller tubes.

MECHANICAL DATA

Dimensions in mm (and inches)

Fig.1



tube must not be clamped within 50mm of either end

CATHODE

OATTIODE		
Thickness	30 – 40	mg/cm ²
Sensitive length	220	mm
	8.7	inches
Material	chrome iron	
FILLING	neon, argon, halogen	
CAPACITANCE		
Anode to cathode	6	pF
TUBE WEIGHT	20	g

OPERATING CHARACTERISTICS (Ambient tempera	sture \approx 25 °C)		
Measured in circuit of Fig.2			
Starting voltage	max.	825	V
Plateau threshold voltage	max.	875	V
Plateau length		200	V
Recommended supply voltage		975	V
Plateau slope	max.	0.1	%/V
Background (shielded with 50 mm Pb with an inner liner of 6 mm Al), at recommended supply voltage	max.	75	count/min
Dead time, at recommended supply voltage	max.	100	μs
LIMITING VALUES (Absolute max. rating system)			
Anode resistor	min.	0	Ω M
Anode voltage	max.	1075	V
Ambient temperature			
continuous operating	max. min.	+75 -35	oC oC
storage	max.	+75	oC
LIFE EXPECTANCY			
Life expectancy at ≈ 25 °C		1010	count







Fig.2




Typical counting rate as a function of dose rate (137Cs)



Typical current as a function of dose rate (137 Cs)



Typical dead time as a function of supply voltage



Typical energy response relative to 137Cs

Electronic components and materials for professional, industrial and consumer uses from the world-wide Philips Group of Companies

Argentina: PHILIPS ARGENTINA S.A., Div. Elcoma, Vedia 3892, 1430 BUENOS AIRES, Tel. 541-7141/7242/7343/7444/7545.

Australia: PHILIPS INDUSTRIES HOLDINGS LTD., Elcoma Division, 11 Waltham Street, ARTARMON, N.S.W. 2064, Tel. (02) 439 3322.

Austria: ÖSTERREICHISCHE PHILIPS BAUELEMENTE INDUSTRIE G.m.b.H., Triester Str. 64, A-1101 WIEN, Tel. 629111-0.

Belgium: N.V. PHILIPS & MBLE ASSOCIATED, 9 rue du Pavillon, B-1030 BRUXELLES, Tel. (02) 2427400.

Brazil: IBRAPE, Caixa Postal 7383, Av. Brigadeiro Faria Lima, 1735 SAO PAULO, SP, Tel. (011) 211-2600.

Canada: PHILIPS ELECTRONICS LTD., Elcoma Division, 601 Milner Ave., SCARBOROUGH, Ontario, M1B 1M8, Tel. 292-5161.

Chile: PHILIPS CHILENA S.A., Av. Santa Maria 0760, SANTIAGO, Tel. 39-4001.

Colombia: IND. PHILIPS DE COLOMBIA S.A., c/o IPRELENSO LTD., Cra. 21, No. 56-17, BOGOTA, D.E., Tel. 2497624.

Denmark: MINIWATT A/S, Strandlodsvej 2, P.O. Box 1919, DK 2300 COPENHAGEN S, Tel. (01) 541133.

Finland: OY PHILIPS AB, Elcoma Division, Kaivokatu 8, SF-00100 HELSINKI 10, Tel. 17271.

France: RTC-COMPELEC, 130 Avenue Ledru Rollin, F-75540 PARIS 11, Tel. 43388000.

Germany (Fed. Republic): VALVO, UB Bauelemente der Philips G.m.b.H., Valvo Haus, Burchardstrasse 19, D-2 HAMBURG 1, Tel. (040) 3296-0.

Greece: PHILIPS HELLENIQUE S.A., Elcoma Division, 54, Syngru Av., ATHENS 11742, Tel. 9215311/319.

Hong Kong: PHILIPS HONG KONG LTD., Elcoma Div., 15/F Phillips Ind. Bldg., 24-28 Kung Yip St., KWAI CHUNG, Tel. (0)-245121. India: PEICO ELECTRONICS & ELECTRICALS LTD., Elcoma Dept., Band Box Building,

254-D Dr. Annie Besant Rd., BOMBAY - 400 025, Tel. 4930311/4930590.

Indonesia: P.T. PHILIPS-RALIN ELECTRONICS, Elcoma Div., Setiabudi II Building, 6th Fl., Jalan H.R. Rasuna Said (P.O. Box 223/KBY) Kuningan, JAKARTA – Selatan, Tel. 512572.

Ireland: PHILIPS ELECTRICAL (IRELAND) LTD., Newstead, Clonskeagh, DUBLIN 14, Tel. 693355.

Italy: PHILIPS S.p.A., Sezione Elcoma, Piazza IV Novembre 3, I-20124 MILANO, Tel. 2-6752.1.

Japan: NIHON PHILIPS CORP., Shuwa Shinagawa Bldg., 26-33 Takanawa 3-chome, Minato-ku, TOKYO (108), Tel. 448-5611.

(IC Products) SIGNETICS JAPAN LTD., 8-7 Sanbancho Chiyoda-ku, TOKYO 102, Tel. (03) 230-1521.

Korea (Republic of): PHILIPS ELECTRONICS (KOREA) LTD., Elcoma Div., Philips House, 260-199 Itaewon-dong, Yongsan-ku, SEOUL, Tel. 794-5011.

Malaysia: PHILIPS MALAYSIA SDN. BERHAD, No. 4 Persiaran Barat, Petaling Jaya, P.O.B. 2163, KUALA LUMPUR, Selangor, Tel. 774411.

Mexico: ELECTRONICA, S.A de C.V., Carr. México-Toluca km. 62.5, TOLUCA, Edo. de México 50140, Tel. Toluca 91 (721) 613-00.

Netherlands: PHILIPS NEDERLAND, Marktgroep Elonco, Postbus 90050, 5600 PB EINDHOVEN, Tel. (040) 793333.

New Zealand: PHILIPS NEW ZEALAND LTD., Elcoma Division, 110 Mt. Eden Road, C.P.O. Box 1041, AUCKLAND, Tel. 605-914.

Norway: NORSK A/S PHILIPS, Electronica Dept., Sandstuveien 70, OSLO 6, Tel. 68 02 00.

Peru: CADESA, Av. Alfonso Ugarte 1268, LIMA 5, Tel. 326070.

Philippines: PHILIPS INDUSTRIAL DEV. INC., 2246 Pasong Tamo, P.O. Box 911, Makati Comm. Centre, MAKATI-RIZAL 3116, Tel. 86-89-51 to 59.

Portugal: PHILIPS PORTUGUESA S.A.R.L., Av. Eng. Duarte Pacheco 6, 1009 LISBOA Codex, Tel. 683121.

Singapore: PHILIPS PROJECT DEV. (Singapore) PTE LTD., Elcoma Div., Lorong 1, Toa Payoh, SINGAPORE 1231, Tel. 3502 000.

South Africa: EDAC (PTY.) LTD., 3rd Floor Rainer House, Upper Railway Rd. & Ove St., New Doornfontein, JOHANNESBURG 2001, Tel. 614-2362/9.

Spain: MINIWATT S.A., Balmes 22, BARCELONA 7, Tel. 3016312.

Sweden: PHILIPS KOMPONENTER A.B., Lidingövägen 50, S-11584 STOCKHOLM 27, Tel. 08/7821000.

Switzerland: PHILIPS A.G., Elcoma Dept., Allmendstrasse 140-142, CH-8027 ZÜRICH, Tel. 01-4882211.

Taiwan: PHILIPS TAIWAN LTD., 150 Tun Hua North Road, P.O. Box 22978, TAIPEI, Taiwan, Tel. 7120500.

Thailand: PHILIPS ELECTRICAL CO. OF THAILAND LTD., 283 Silom Road, P.O. Box 961, BANGKOK, Tel. 233-6330-9.

Turkey: TÜRK PHILIPS TICARET A.S., Elcoma Department, Inönü Cad, No. 78-80, P.K.504, 80074 ISTANBUL, Tel. 4359 10.

United Kingdom: MULLARD LTD., Mullard House, Torrington Place, LONDON WC1E 7HD, Tel. 01-580 6633.

United States: (Active Devices & Materials) AMPEREX SALES CORP., Providence Pike, SLATERSVILLE, R.I. 02876, Tel. (401) 762-9000.

(Passive Devices) MEPCO/ELECTRA INC., Columbia Rd., MORRISTOWN, N.J. 07960, Tel. (201) 539-2000.

(Passive Devices & Electromechanical Devices) CENTRALAB INC., 5855 N. Glen Park Rd., MILWAUKEE, WI 53201, Tel. (414)228-7380.

(IC Products) SIGNETICS CORPORATION, 811 East Arques Avenue, SUNNYVALE, California 94086, Tel. (408) 991-2000.

Uruguay: LUZILECTRON S.A., Avda Uruguay 1287, P.O. Box 907, MONTEVIDEO, Tel. 914321.

Venezuela: IND. VENEZOLANAS PHILIPS S.A., c/o MAGNETICA S.A., Calle 6, Ed. Las Tres Jotas, App. Post. 78117, CARACAS, Tel. (02) 2393931.

For all other countries apply to: Philips Electronic Components and Materials Division, International Business Relations, P.O. Box 218, 5600 MD EINDHOVEN, The Netherlands, Telex 35000 phtcnl

AS52

© Philips Export B.V. 1986

This information is furnished for guidance, and with no guarantee as to its accuracy or completeness; its publication conveys no licence under any patent or other right, nor does the publisher assume liability for any consequence of its use; specifications and availability of goods mentioned in it are subject to change without notice; it is not to be reproduced in any way, in whole or in part, without the written consent of the publisher.

Printed in England

9398 139 30011