The Type 7590 is a three element unipotential cathode hydrogen thyratron designed for "crow-bar" service. This tube is equipped with a hydrogen reservoir for maximum dependability.

GENERAL CHARACTERISTICS

Nom.

Min.

Max.

Heater Voltage Heater Current (at 6.3 volts) Reservoir Voltage (Note 1) Reservoir Current at 4.5 Volts Minimum Heating Time	6.3	6.0 12.0 2.5 2.0	6.6 22.0 5.5 5.0 3	Volts AC Amperes Volts Amperes Minutes
Mechanical Mounting Position Base Cooling (Note 2) Net Weight Dimensions			1.5	Any See Outline Pounds Per Outline
MAXIMUM RATINGS				
Max. Peak Anode Voltage, Forward, Transient (Note 3) Max. Peak Anode Voltage, Forward, Operating Max. Peak Anode Voltage, Inverse Min. Anode Supply Voltage Max. Peak Anode Current Max. Average Anode Current (Note 4) Averaging Time Max. Discharge Time (Note 4) Max. Anode Current Rate of Rise Peak Trigger Voltage (Note 5) Max. Anode Delay Time Ambient Temperature		·	30.0 25.0 15.0 10.0 1000 500 10 0.1 2500	Kilovolts Kilovolts Kilovolts DC Amperes Milliamperes Seconds Seconds Amps / u sec.

Note 1:

Electrical

Adjust reservoir voltage to value indicated on tube within $\pm 5\%$.

Note 2:

No cooling required.

Note 3:

The maximum peak forward transient anode voltage rating applies to a transient voltage condition wherein the duration of the transient does not exceed two seconds.

Note 4:

The allowable time of discharge varies with the current as shown Filter Discharge Period 0 - 1.5 ms.

Rectifier Short Circuit Period 1.5 - 100 ms 25 a Rectifier Short Circuit Period 1.5 - 50 ms 50 a Rectifier Short Circuit Period 1.5 - 30 ms 85 a

Time will be measured from the initiation of the discharge.

^{*} Indicates change from data sheet dated 6-61

7590 HYDROGEN THYRATRON TUBE

* Note 5:

The driver pulse measured at the tube socket with the thyratron grid disconnected shall be: egy = 550 Volts minimum, 2500 Volts maximum; Rate of Rise 1800 Volts per Microsecond; tp = 2.0 Microseconds minimum; Impedance of Driver Circuit 50 - 200 Ohms.

Additional information for specific applications can be obtained from the

Electron Tube Applications Section ITT Electron Tube Division P. 0. Box 100 Easton, Pennsylvania

• Indicates change from data sheet dated 6-61

